




LP1031

Focusing LED Keychain Flashlight



1 AAA
Batteries

ANSI/PLATO FL1 STANDARD			
			
MODES	LUMENS	RUN TIME	BEAM DISTANCE
High	40lm	45m	10 m

Features

- Durable aluminum construction
- LED flashlight
- Enhanced grip
- High quality keychain
- Tactical tail cap button
- O-ring sealed, weather-resistant

Operation Instructions

- On/Off: Press and release button.
- Focus head: Push head away from flashlight to narrow beam. Pull head towards flashlight to widen beam.

Usage and Maintenance

- Battery Replacement:** In a dry environment, unscrew the tailcap by turning counter clockwise. Remove batteries. Insert the new batteries into the tube (+) end first. Carefully reinstall the tailcap by pressing lightly while turning clockwise.
- Care Instructions:** If you know it's going to be a while between uses, we suggest removing batteries from your light and storing your gear in a dry, protected place.

Company Contact

Limited 30-Day Warranty against manufacturer's defects from time of purchase. For warranty claims contact LuxPro by calling 801-553-8886 or sending an email to info@simpleproducts.com.