

LP1040

LED Pen Light



Features

- Durable aluminum construction
- LPE Optics
- Textured grip
- High quality pocket clip
- Tactical tail cap button
- O-ring sealed, IPX4
- 2 Modes: High/Low

Operation Instructions

- On/Off: Press and release button
- Cycle modes: From High mode, half-press button to cycle through modes (High/Low).
- Automatically resets to High mode when off.

Usage and Maintenance

Battery Replacement: In a dry environment, unscrew the tailcap by turning counter clockwise. Remove battery. Insert the new battery into the tube (+) end first. Carefully reinstall the tailcap by pressing lightly while turning clockwise.

Care Instructions: If you know it's going to be a while between uses, we suggest removing batteries from your light and storing your gear in a dry, protected place.

Product Warranty

Limited Lifetime Warranty against manufacturer's defects. For warranty claims contact LuxPro by calling 801-553-8886 or sending an email to info@simpleproducts.com.

1 AAA Batteries

ANSI/PLATO FL1 STANDARD			
MODES	LUMENS	RUN TIME	BEAM DISTANCE
High	85 lm	1h	40 m
Low	35 lm	2h	20 m