

LP1200

High-Output Large Flashlight







6	AA Batteries	

ANSI/PLATO FL1 STANDARD			
MODES	LUMENS	RUN TIME	BEAM DISTANCE
High	650 lm	3 h 30 m	380 m
Low	250 lm	5h	200 m
Strobe	650 lm	-	-

Features

Durable aluminum construction

Long range LPE Optics

Rubber grip

Heavy duty flashlight

Ergonomic side button

O-ring sealed, IPX4

Uses 3AA or 6AA

3 Modes: High/Low/Strobe

Operation Instructions

On/Off: Press and release button.

Cycle modes: From High mode, half-press button to cycle through modes (High/Low/Strobe).

Automatically resets to High mode when off for longer than 2 seconds.

Usage and Maintenance

Battery Replacement: In a dry environment, unscrew the tailcap by turning counter clockwise. Remove the batteries from the battery tubes. Insert new batteries into the tubes according to the (+/-) symbols on the flashlight. Carefully reinstall the tailcap by pressing lightly while turning clockwise until tight.

Care Instructions: If you know it's going to be a while between uses, we suggest removing batteries from your light and storing your gear in a dry, protected place.

Product Warranty

Limited Lifetime Warranty against manufacturer's defects. For warranty claims contact LuxPro by calling 801-553-8886 or sending an email to info@simpleproducts.com.