

LP137

Combo LED Pocket Worklight



Features

Compact, Rugged design

Area light, LED flashlight

Non-slip plastic mold

Magnetic swivel pocket clip

Side button operation

3 Modes: High Area / Low Area / High Flashlight

Weather resistant IPX4

Operation Instructions

On/Off: Press power button and release

Cycle Modes: Press and release button (Flashlight High/ Area High/Area Low)

Usage and Maintenance

Battery Replacement: In a dry environment, unscrew the tailcap by turning counter clockwise. Remove batteries. Insert the new batteries into the tube (+) end first. Carefully reinstall the tailcap by pressing lightly while turning clockwise.

Care Instructions: If you know it's going to be a while between uses, we suggest removing batteries from your light and storing your gear in a dry, protected place.





ANSI/PLATO FL1 STANDARD			
	31/5	(1)	BEAM
MODES	LUMENS	RUNTIME	DISTANCE
Area High	220 lm	2h 30m	15 m
Area Low	80lm	3h 30m	10 m
Flashlight High	65 lm	4h 30m	15 m

Product Warranty

Limited 90-Day Warranty against manufacturer's defects from time of purchase. For warranty claims contact LuxPro by calling 801-553-8886 or sending an email to info@simpleproducts.com.