

# **LP**459


## **Utility LED Flashlight with Area Light**











#### **Features**

Durable aluminum construction

BROADBEAM surface LED, high efficiency LED flashlight

Strong magnetic base

Ergonomic side button

O-ring sealed, IPX4

Variable brightness

LPE Optics

#### **Operation Instructions**

On/Off: Press and release button

To access the area light, pull down from the base of the light.

Adjusting brightness in Flashlight/Area light modes: Press and hold button down. Light emitted will increase/decrease with a quick pause in the beam to indicate highest/lowest light output.

Automatically resets to High mode when turned off.

### **Usage and Maintenance**

Battery Replacement: In a dry environment, unscrew the tailcap by turning counter clockwise. There will then be an inner tailcap that is also removed by turning counter clockwise. Remove batteries. Insert the new batteries into the tubes according to the (+/-) symbols. Carefully reinstall each tailcap by pressing lightly while turning clockwise.

Care Instructions: If you know it's going to be a while between uses, we suggest removing batteries from your light and storing your gear in a dry, protected place.

#### **Product Warranty**

Limited Lifetime Warranty against manufacturer's defects. For warranty claims contact LuxPro by calling 801-553-8886 or sending an email to info@simpleproducts.com.