

# LP800

## Small Universal Flashlight



### Features

- Durable aluminum construction
- High efficiency LED
- Enhanced rubber grip
- High quality wrist lanyard
- Tactical tail cap button
- O-ring sealed, weather-resistant

### Operation Instructions

On/Off: Press and release button

Cycle modes: From High mode, press button to cycle through modes (High/Low/Strobe).

### Usage and Maintenance

**Battery Replacement:** In a dry environment, unscrew the tailcap by turning counter clockwise. Remove the battery case from the flashlight by tipping the bottom of the light downward until it slides free from the tube. With the battery case now out of the flashlight, remove the batteries from the case. Insert new batteries into the case according to the (+/-) symbols found on the case. Insert the battery case into the light according to the directional arrow on the outside of the case. Carefully reinstall the tailcap by pressing lightly while turning clockwise until tight.

**Care Instructions:** If you know it's going to be a while between uses, we suggest removing batteries from your light and storing your gear in a dry, protected place.

### Product Warranty

Limited 30-Day Warranty against manufacturer's defects from time of purchase. For warranty claims contact LuxPro by calling 801-553-8886 or sending an email to [info@simpleproducts.com](mailto:info@simpleproducts.com).

**3** AAA Batteries

ANSI/PLATO FL1 STANDARD			
MODES	LUMENS	RUN TIME	BEAM DISTANCE
High	160 lm	2h 30m	60 m
Low	61 lm	3h 45m	30 m
Strobe	160 lm	-	-