

LP860

LED Spotlight with Red Lens



4 AA Batteries

Features

- Rugged design
- Locking trigger
- Ergonomic handle
- Red lens cover
- Power adapter included
- 3 Modes: High / Low / Strobe
- Weather resistant IPX4

Operation Instructions

On/Off: Pull and release trigger. To keep the light on, pull the trigger and engage the trigger lock by sliding the lock button on the left side of the handle downward. Unlock the trigger by sliding the lock button upward.

Cycle Modes: Pull and release trigger (High/Low/Strobe)

Usage and Maintenance

Battery Replacement: In a dry environment, unscrew the back of the light by turning counter clockwise. Remove batteries. Insert new batteries into the battery slots taking note of +/- symbols. Carefully reinstall the back of the light by pressing lightly while turning clockwise.

To Use Power Adaptor: Plug the small end of the cord into the port located under the rubber dust cover on the bottom of the light handle. Plug the larger end of the cord into an automotive power socket.

Care Instructions: If you know it's going to be a while between uses, we suggest removing batteries from your light and storing your gear in a dry, protected place.

Product Warranty

Limited 90-Day Warranty against manufacturer's defects from time of purchase. For warranty claims contact LuxPro by calling 801-553-8886 or sending an email to info@simpleproducts.com.

ANSI/PLATO FL1 STANDARD			
MODES	LUMENS	RUN TIME	BEAM DISTANCE
High	330lm	3 h	320 m
Low	80lm	14 h	150 m