

LP9UV

UV Illuminator Light 9-LED



Operating Ultraviolet light 385-390nm.

Features

Durable aluminum construction

9 UV LED flashlight

Enhanced rubber grip

High quality wrist lanyard

Tactical tail cap button

Ultraviolet flashlight

Operation Instructions

On/Off: Press button to activate. Press again to turn off.

Usage and Maintenance

Battery Replacement: In a dry environment, unscrew the tailcap by turning counter clockwise. Remove the battery case from the flashlight by tipping the bottom of the light downward until it slides free from the tube. With the battery case now out of the flashlight, remove the batteries from the case. Insert new batteries into the case according to the (+/-) symbols found on the case. Insert the battery case into the light according to the directional arrow on the outside of the case. Carefully reinstall the tailcap by pressing lightly while turning clockwise until tight.

Care Instructions: If you know it's going to be a while between uses, we suggest removing batteries from your light and storing your gear in a dry, protected place.

Product Warranty

Limited 30-Day Warranty against manufacturer's defects from time of purchase. For warranty claims contact LuxPro by calling 801-553-8886 or sending an email to info@simpleproducts.com.