

## XP910

### Rechargeable Tactical LED Flashlight



#### Features

- Constructed with aircraft-grade aluminum
- LPE optics
- Patented TackGrip molded rubber grip
- High quality, extra deep pocket clip
- Mode selection dial
- Soft touch tactical tail cap
- IPX6 waterproof rating
- Rechargeable 18650 battery with charging cradle

#### Product Warranty

The XP910 has a Limited Lifetime Warranty Against Manufacturer's Defects from time of purchase. For warranty claims please contact us by calling 801-553-8886 or sending an email to [info@simpleproducts.com](mailto:info@simpleproducts.com)

#### ANSI/PLATO FL1 STANDARD

MODES	LUMENS	RUN TIME	BEAM DISTANCE
High	1000 lm	3h 30m	160m
Medium	250 lm	5h 30m	70m
Low	25 lm	60h	41m
Strobe	1000 lm	--	--

#### Operation Instructions

**On/Off:** Press and release the button on the tail cap to turn the light on and off.

**Momentary On:** While the light is off, half-press button on tail cap to momentarily turn the flashlight on.



**Cycle Modes:** Rotate the mode dial near the head of the flashlight to select the desired mode (High/Medium/Ultra-Low/Strobe). Dial can be rotated while the light is on or off and can be used to select the desired mode prior to turning the flashlight on.

#### Charging Instructions

To charge the flashlight, the re-chargeable battery must first be removed from the light. Turn the tail cap counterclockwise to remove it. Tip the light downward to slide out the LUXPRO 18650 re-chargeable battery.

Place the battery into the provided battery charging cradle according to the (+/-) symbols on the charging cradle.

Plug Micro-USB (included) into 5V power source. The LED light on the cradle will be red while charging, then turn green to indicate the battery is fully charged.



Included Lithium battery has a charge time of approximately 3 hours.

#### Battery Replacement

The XP910 also be used with 2 X CR123 Li-Ion batteries. To replace the batteries, turn the tail cap counterclockwise to remove it. Tip the light downward to slide out the existing battery. Insert new batteries into the light (+) side first. For best results, we recommend using brand new batteries that are the same voltage and brand.

Re-attach tail cap by pressing down lightly and turning it clockwise until tight.



If you know it will be a while between uses, we suggest removing the batteries from the flashlight and storing it in a dry, protected place.