

KT612 Guitar Function Instructions

PC/PS3 2-in-1 Guitar





Tour/Guitar Hero Aerosmith/GAME: PS3 platform Guitar Hero 4/Guitar Hero

2(3) (4) (5(8)(Z)

16 17 (6)


to realize the wireless connection with the guitar. Turn on the power switch of 9. PS button: PS3 platform press the PS button to the menu, select a channel or

support Guitar Heo 3/Guitar Heo 3 Legends Of Rock/Guitar Hero World 10. Channel LED indicators.

14. Guitar decorative face lock.

19. Receiver: The red and blue lights on the PC platform are on at the same | • Install the strap 1. First take out the strap in the box.

The product supports standard LR6 (AA) batteries, and the package does not time, please put the absorbent sponge back to its original position



4. Whammy bar: When there is a long sound in the game, you can change the sound effect in the game by patting the pressure rod. 5. "+"key:PS3 platform pause and start key.PC platform confirmation key.

6. "-"key: PS3 platform selection key.PC platform Esc function, or pause.

Introduction

8 Strum key: In the game, when the melody pluck keys corresponding to 1. This guitar is a wireless 2-in-1 guitar that uses 2.4G RF technology. By different colors are operated at the same time as the playing button, it will connecting the receiver to the PS3 console or the USB interface of the computer | produce different melodies.

the guitar to connect to the receiver autosomally without code pairing. Support exit the game, wake up the guitar in sleep, and other functions; the PC plat-PS3/PC platform, PS3 support Guitar Hero 3/Rockban game, PC platform form wakes up the guitar and Menu function.

Battery cover

17. Guitar rod lock.

15. AA battery compartment.

16. Power toggle switch

time: the blue light is on in Guitar Hero mode on the PS3 platform, and the red light is on in the Rockband game mode.

Guitar pole installation and removal

3. You can adjust the length of the strap according to your needs 1. Please take out the absorbent sponge from the main body of the guitar first (shown in the box below). The absorbent sponge is to protect the probes inside | • Install the battery the guitar from being easily oxidized. When the guitar is not used for a long



2. Take out the guitar rod from the packing box, insert the guitar rod into the guitar body according to the picture, and hear the sound of "click" to indicate that it has been inserted in right place and locked automatically.

If you need a two-player game on the PC side, you need to set the second | First of all, after the guitar and the receiver are successfully connected, the guitar to Xinput mode. The setting method is to press the guitar's "-"button | blue light of the receiver is on. The default Guitar Hero game mode, if you are and "PS" button for 3 seconds at the same time when the guitar is in the wireless connection state. After the switch is successful, the first light of the guitar for 2 seconds, and wait for the LED on the receiver to turn into a red guitar turns to the second light. Note that Guitar Hero games in Xinput mode light. It means that the Rockband game mode is switched successfully. do not support the strum key, and other functions can be used normally.



3.If you need to remove the guitar rod, please turn the lock to the unlocked

position first, and then carefully pull out the guitar rod.

- Connecting PS3 game console
- 2. Use the holes at both sides of the strap to connect to the strap buckle on the First turn on the power switch in the battery cover of the guitar and toggle it to the ON state, then insert the receiver into the USB socket of the PS3 game console, the guitar will be automatically paired with the receiver, and the blue

Press the - key and PS key simultaneously for 3 seconds

light of the receiver will always be on after the connection is successful, indi-

Guitar Mode Settings

(If it enters sleep mode, please press the PS button of the guitar to wake up the include battery accessories. Consumers need to purchase according to this guitar and connect automatically)

1. Before installing the battery, check that the switch is toggled to the off state

2. Please install the batteries correctly according to the polarity markings.

. After the battery is installed, please check whether the battery is installed

4. Turn the switch to ON, and close the battery cover.

ON OFF STAA G MAA G M

Switch between Hero and Rockband games

• Connecting a Windows computer

the ON state, then insert the receiver into the USB socket of the computer con-


successful, indicating that the connection is successful. (If it enters sleep

COMPTHEE OF

For example, set Guitar Hero Aero smith for left-handed or right-handed use

sole, the guitar will automatically pair and connect to the receiver, and the red and blue lights of the receiver will always be on after the connection is

mode, please press the PS button of the guitar to wake up the guitar and concating that the connection is successful: The guitar is now in Guitar Hero




Note that after entering the game on the PC side, some games default to left-handed playing, which can be set in the guitar game.

After entering the game, press the green button of the guitar to confirm, and the-key to return; press the arrow keys to select OPTIONS below, and press the green button to confirm.



For notes with long notes in the game, when the note appears, the right hand can Select CONTROLLER below and press the green key to confirm pluck the string key once, but the left hand must press and hold the key at the

View Keyboard Defaults



Cancel $\sqrt{}$ at the P1 position in the figure below, it is a right-handed button for 5 seconds during use, and the guitar will enter sleep mode. mode, if you add $\sqrt{}$ that it is the left-handed mode. (When $\sqrt{}$ of both P1 and When the guitar is sleeping, you can press the "+" button on the guitar or pres in the right-handed mode of the two-player game are canceled.

Battery Voltage instructions

• Use of the Tone Down Lever

When the battery voltage is lower than the preset value, the guitar LED wil flash and disconnect, reminding us to replace the battery. When it is lower than the lowest preset value, it will automatically shut down.




• Instructions on how to play Clone Heroes 1. Enter the URL http://chonehero.net/. Download and install the game. (or

download games from other sites) 2. Start the game. Enter the game interface, press the Enter key to register a

game account name, after registering the name, click the Space key to enter the button settings, set the corresponding buttons according to the corresponding 2.Guitar has no function and the light is not on? Please check whether the positive and negative poles of the battery inside

Done Restore Defaults




4. The pressure rod is not functioning or the pressure rod is abnormal?

the game exceeds 50%, quickly erect the guitar, the color of the game scroll will rod. Please turn off the power switch and turn on the power again. 5. Guitar rod buttons don't work?

When the guitar and receiver are connected, when there is no button action bent or blocked by other things. If the metal probe point of the guitar rod is white the guitar end for 3 minutes, the guitar will enter sleep mode; press and hold or black, it means that there is an oxide coating, please use an alcohol clo th or eraser to gently wipe metal probe points. (If the guitar is not used for a long time, please pack it in a plastic bag and store it to avoid oxidation of the metal the "PS" button to wake up the guitar and connect automatically.

place, and do not expose the product to the sun.



When you press the orange key during the setting process, if there is a stick key reminder, you need to turn off the sticky function of the keyboard, do ble-click the link at the arrow position in the figure below, or directly enter the 6. When the product is not in use, do not put the product in a humid or dus

MADE IN CHINA After entering the keyboard settings, cancel the $\sqrt{}$ in front of the two sticky f

tions in the figure below, and then click Apply in the lower right corner.

E Lock modifier keys when present back in a row IV Turn off Sticky Keys when two less are present at once

Keyboard

With the sticky feature turned off, you can use the orange button of the guitar

If Digglay the Sticky Keys icon on the task from