


functions for each key may be possible to change/assign within the settings

me racing wheel that supports the PS4/PS3/PC/Nintendo Switch/Android 2. The racing wheel also has a sensitivity adjustment function. According to

this button is the menu button and informs the system that the racing wheel is





1. The function keys are the L1/R1/L2/R2/L3/R3/ \triangle / \bigcirc \times / \Box key, and the operation .. This racing wheel can be rotated 180 degrees. It is a multi-function version | | tion command is issued to have different functions in different games.


he default is level 4. The sensitivity of each level corresponds to differ different game requirements, you can set 7 levels of sensitivity, the default is nds, enter the sensitivity adjustment program, the LED light flashes

. Support for the adjustment of the tilt angle of the wheel column. You can














nstructions to insert the pedals unit USB first into the racing wheel and then













controller and comes with a USB interface. Connect the Android device to the

steering wheel USB interface. The steering wheel LED lights to indicate successful

connection. After the link is successful, you can download the game in Androic

NOTE: Android platform instructions: Android mode needs to be initiated before

Android host, then hold L3+R3 for three seconds at the same time, the LED flash-

it can be used; Operation method: connect the steering wheel USB cable to the

device's own application market to test the steering wheel function.

s once to indicate that the switch is successful.

(Nintendo Switch Connect Method)

ostructions to insert the pedals unit USB first into the racing wheel and the

seconds to switch to DirectInput mode.

4. Graphics: MX440 or higher

ompleted open the game and go to Settings for the game and set

Need For Speed:Hot Pursuit 14 Need For Speed:Hot Pursuit 15 DIRT:Colin McRae Off-Road

XInput and DirectInput. The default is XInput mode, press the PS key for about 3

* 480 resolution. If you want a better effect and higher resolution, pleas upgrade the memory, CPU and/or graphics card. Most newer computers have more than adequate specifications.

You can switch between XInput mode and DirectInput mode by pressing th 3. Click to install the game, select the installation path. Once the installation i steering wheel's PS button for 3 seconds. In Windows 7 and later systems, th XInput mode game controller will use the standard Windows XInput gam

The steering wheel supports XInput and the older DirectInput interface mode.



orts the XInput game controller and the steering whee

■ Connect the Computer

2/B, 3/X, 4/Y, 5/LB, 6/RB, 7/LT, 8/RT, the computer and the system will

 light, let go after extinguished. ou can see that the "USB

automatically recognize it as "USB

Controller" status "OK" i

steering wheel is connected to

(Image 1). This shows that the

In this interface you can see the inter

Here, you can test the steering

position of the wheel. If there is a

deviation from the roulette wheel, you

restore it and let the joystick return to the initial state (Note: The normal axis is centered at 127. If there is a slight

can click "Default" at this point to

wheel's accuracy and adjust the initial

9/SELECT, 10/ START press any key to

1. Important ergonomic information: Prolonged repetitive movements, improp

weakness, swelling, burning, cramping, or stiffness in your palms, wrists, arms,

shoulders, neck, or back, stop playing. If the problem persists, have a qualified

3. Please do not use the product in humid conditions, around fumes, dust ar extreme temperatures; limit direct sun exposure, use mild cleaners to clean, and

working spaces, improper body posture or poor play habits may cause discon

vibration of the steering wheel;

you can also adjust the vibration

and the vibration effect of the

pressing the pedal unit's gas and

steering wheel will be detected by

A: This device does not support Xbox 360, Xbox one, and PS4

Q: Will this work for American Truck sim on ma-

game settings, change the game controller, and set the button on it.

A: It is not guaranteed to work in this game.

A: Yes. Please open the game, press the "ESC" on the keyboard to open the

Q: Does this work with Need for Speed Rivals and Forza Motorsport 3 or

A: No, you just plug the USB of the pedal into the USB interface of the main steering wheel. The USB of the pedal is not used to connect the computer.

O: Can this work for Assetto Corsa on PC?

Q: Does this work with Need for Speed Most Wanted?

Q: How is this mounted? Are there optional bolt mour A: 1. Find the locking clips underneath the racing whee

A: Because the steering wheel's angle range is now fixed, you can try different

Q: It's good but how do I change more of the sensitivity? I tried all the sensitivity

O: Will this work on Assetto Corsa (Steam edition) on PC, Windows 10?

Q: Does this have force feedback?

Q: Does it work with a PC Forza Horizon 4 Ultimate Edition?

A: It depends on the game.