



VIVE Wireless Adapter Full Pack

Untethered virtual reality is here.

For Pro Series / Pro Eye Series / Cosmos Series*



LET NOTHING HOLD YOU BACK

Introducing the official wireless VR adapter for VIVE Cosmos and VIVE Pro Series. Move without hindrance. Broaden your virtual horizons. Make multiuser virtual reality an actuality.

FREEDOM, UNINTERRUPTED

The VIVE Wireless Adapter, powered by Intel® WiGig, offers a near-zero latency VR experience that's fast, responsive and offers maximum performance. Build worlds, tear them down, venture into the unknown — all without skipping a beat. Plus, it's so lightweight, you'll barely notice it's there.

MORE PLAYERS? NO PROBLEM**

Remove cables from the equation with the VIVE Wireless Adapter. More easily get friends, family, and the uninitiated in your play space. Break free of always being a one-person team.

UNLOCK THE FULL POTENTIAL OF VIVE

Easy to set up, the VIVE Wireless Adapter helps you get the most out of SteamVR's room-scale tracking technology. Coupled with a powerful, easy-swap battery, you can explore the full virtual range of your VIVE Cosmos or VIVE Pro Series for up to 2.5 hours.



VIVE Wireless Adapter
Untethered virtual reality is here.

*** Requirements of the headset**

Requires available PCIe slot.
Wireless Adapter for VIVE Cosmos only works with the 21-Watt battery included in the kit.

**** Multiplayers requirements**

Wireless Adapter can support both VIVE Base Station and SteamVR Base Station 2.0.
Use up to 3 VIVE Wireless Adapters in a single-room-scale environment. Region dependent.
Additional purchase required for VIVE Cosmos and VIVE Pro Series.
Spare PCIe 1x slot required.



TECHNICAL SPECS

VIVE WIRELESS ADAPTER SPECS

- Commercial Product Name:** VIVE Wireless Adapter Full Pack
- Dimensions:** 7.87 x 3.81 x 1.59 inches
(200 x 96.65 x 40.43 mm)
- Weight:** 4.55 ounces (129 grams)
- Battery Life:** Up to 2.5 hours
- Connection Type(s):**
- For VIVE Pro/VIVE Pro Eye Series: Respective single port
 - For VIVE Cosmos Series: Respective single port
 - For battery: USB


MINIMUM REQUIREMENTS

- Computer Type:** Desktop computer with available PCIe Slot
- Processor:** Intel® Core™ i5-4590 or AMD FX™ 8350 equivalent or better"
- GPU:** NVIDIA® GeForce® GTX 1060, AMD Radeon™ RX 480 equivalent or better
- Memory:** 4 GB RAM or more"
- Operating system:**
- For VIVE Pro/VIVE Pro Eye Series: 64-bit Windows® 10 or Windows® 7 SP1
 - For VIVE Cosmos Series: 64-bit Windows® 10

INCLUDED IN THE BOX



Wireless adapter




Wireless link box



Wireless link box clip




PCIe WiGig card




Short headset cable




Power bank



Power bank holder



Power cable



Power bank charging cable



Thin velcro pad (for Cosmos Series)



Head pad (for Cosmos Series)



Head pad (for Pro/Pro Eye Series)

