



## The special instructions for new Cargo bikes

### 1. Assembling the battery

Firstly put the battery box into the frame under the carriage. Fix the battery box with battery hook and battery clamp provided.



Then open the switch(A).



### 2. Speed switch



I : low speed

II: high speed

III: middle speed

### 3. Gear shift

The new Cargo bike has two gears, high-grade and low-grade. When climbing and very difficult to climb, you can stop the Cargo bike, and then change the low-grade to climb.



**Note1: When changing the gears, you must stop the Cargo bike.**

**Note2: When stopping the Cargo bike, please pull the hand brake.**

