

Card rack w/stand set for 35° angle.

Card rack w/stand set for 55° angle.

The stand is installed by sliding the square end thru a pair of slots on the back of the card rack. To change the angle position of the rack, turn the stand over. (see diagram above)

