Levana®

NALA 1080P 5.5" FHD BABY MONITOR

QUICK START GUIDE

For support during the beta trial, contact us at:

beta@etinc.ca

WARNING

STRANGULATION HAZARD: Children have STRANGLED in cords. Keep this cord out of reach of children (more than 3ft. (0.9 m) away).

ACCIDENT PROTECTION PLAN

Full 2 Year Coverage
Full monitor protection from accidental damage caused by liquid or drops & a full 2 year extended warranty for your entire unit.

Free Advanced Replacements
Receive your new monitor before shipping back the old one. Shipping is on us!

Purchase Anytime Within The First Year

Learn More
**mylevana.com/accidentshappen**

Worry Less. Do More.®

Learn about all of your Nala Baby Monitor's features and tips.

Open camera & scan this QR code to access all Nala support videos or visit: **bit.ly/NalaSupport**

SETTING UP YOUR NALA BABY MONITOR

Charge the Monitor for 7 hours and Plug in the Camera.

- 🟢 Charged
- 🔴 Charging

IMPORTANT: Place your camera(s) no more than 5ft. away from your baby for optimal performance so the sound is clearly heard.

DO NOT mount cameras directly above the baby or on the crib for a safe setup. Power cords must be kept at least 3ft. away from the crib and baby's reach at all times.

GET TO KNOW YOUR NALA BABY MONITOR

LED Indicator

Multifunction Buttons

Antenna - For optimal performance and range, lift the antanna during use.

Speaker

Microphone

Kickstand

MONITOR BUTTONS AND FUNCTIONS

POWER ON/OFF - Press and hold (3s)

ENTER AUDIO ONLY MODE - With Voice Activated mode off, quick press $\mathcal{G}$ to activate audio only mode. (No image will be displayed. Only audio will be heard)

ENTER VOICE ACTIVATED MODE - With Voice Activated mode on, quick press $\mathcal{G}$ to activate voice activated mode. (Screen will wake up when audio is detected)

PAN/TILT - Press to enter Pan & Tilt Function.

PAN/TILT NAVIGATION - With Pan and Tilt function activated, press and hold navigation buttons to view 360°.

VOLUME UP - Press to increase volume and navigate menu up.

VOLUME DOWN - Press to reduce volume and navigate menu down.

ZOOM IN/RIGHT - Press to Zoom in and navigate menu right.

ZOOM OUT/LEFT - Press to Zoom out and navigate menu left.

SEQUENCE MODE - Long press (3s) to enter/exit Sequence Mode.

ACTIVE CAMERA - Quick press to switch between cameras.

OK - Quick press within the menu.

MENU - Quick press to enter the menu.

TWO-WAY TALK - Long press to enable two-way talk.

CAMERA BUTTONS AND FUNCTIONS

IR Sensor

Camera Lens

Power LED

Microphone

Antenna

Speaker

Camera Pairing Button

Power Input

DC 5V

PAIR

Temperature Sensor

Levana

NOTITICATION BAR

| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |

| 📶 | 🔇✗ | 🎵 | ☺))Med | ⏰1h | 🔍x2 | 10:45AM | 🌙 | 70°F | 📷↻① | 🔋 |

1. Connection Strength
2. Monitor Audio Muted
3. Lullaby Playing
4. Voice Activation Mode On
5. Baby Feeding Timer
6. Zoom In Level

7. Current Time
8. Night Vision Activated
9. Temperature (+/- 2-3°)
10. Active Camera (when 2 cameras paired)
11. Battery Level

USING YOUR NALA BABY MONITOR - MENU

1. **Lullaby -** When two cameras are paired, from the live view screen (viewing mode), select the camera (active camera) you wish to activate a lullaby for by pressing 🔊↔🔊. Enter lullaby settings to customize your options.

2. **Voice Activation -** After customizing your setting, short press ⏻ to enter voice activated mode immediately or the monitor will automatically enter this mode after 30s of inactivity.

3. **Monitor Brightness Setting**

4. **Viewing Modes**

   Full Screen Mode ▣ **-** When two cameras are paired, your monitor will automatically enter sequence mode. Long press (3s) to exit Sequence Mode.

   Split Screen ▣ **-** When two cameras are paired, your monitor will automatically enter sequence mode. The active camera is the camera that will have audio. Long press (3s) to exit Sequence Mode.

5. **Camera Pairing**

6. **General Settings**

NALA BABY MONITOR - GENERAL SETTINGS MENU

℃ / ℉ — 1	1. Temperature Settings
🌡 🔊 — 2	2. Temperature Alert Settings
⌚ Clock — 3	3. Clock Setting
🌐 Language — 4	4. Language
⏱ Timer — 5	5. Baby Feeding Reminder Timer
🔊 Alert — 6	6. Alert Monitor Volume
☀ LED — 7	7. LED Indicator Settings
🌙 Night Vision — 8	8. Night Vision Mode
0°/180° — 9	9. Camera Footage View - Invert the camera image.
❓ Support — 10	10. Support Information & Firmware Versions
🔄 Reset — 11	11. Factory Reset

ACTIVATE YOUR WARRANTY

★ Exclusive Member-Only Benefits

🚚 Hassle-Free Replacements

✉ Videos, Tips & Updates

Activate Now
mylevana.com/warranty

For support during the beta trial,
contact us at:

beta@etinc.ca

Worry Less. Do More.®