

Pro U9 Projector

✍ aftersales@yabertech.com 🗐

CONTENTS

YABER LIFETIME PROFESSIONAL SUPPORT	02
TIPS	
PACKAGE LIST	. 03
PROJECTOR SPECIFICATIONS	. 03
PROJECTOR OVERVIEW	. 04
REMOTE CONTROL	
INSTALLATION	
1. Installation Method	
2. Install on the Ceiling	
STARTING PROJECTOR	
IMAGE ADJUSTMENT	
1. Focus Adjustment	. na
2. Image adjustment	
Select the Signal Source	
SETTING UP THE PROJECTOR	. 10
1. Select The Input Signal Source	
USB Disk Input Mode 2.1 Play Video/Music/Picture/Office in the USB Disk Input Mode	. 11
2.2 Video Interface	. 11
2.3 Music Play Interface	
2.4 Office Play Interface	· 12
3. WiFi Setting	
3.1 iOS Cast(for iOS Devices)	
3.2 Miracast(for Android Devices)	
4. Blueteeth Setting	
5. Image Setting	
6. Keystone Setting 6.1 4-corner Keystone	
6.2 4-side Keystone 6.2 4-side Keystone	
6.3 Reset	
7. Projector Position	· 19
8. Custom zoom	. 20
9. System update	
10. Factory Reset	· 20
11. Language	
SIGNAL LINES CONNECTION	· 21
1. Connect USB Disk	
2. Connect the Devices via the HDMI ports	
3. Connect to the DVD Player	
4. Connect to the Soundbar/Speaker	
SAFE SHUTDOWN	
WARRANTY	. 23
TROUBLESHOOTING	. 23

YABER LIFETIME PROFESSIONAL SUPPORT

Dear customer.

Thank you very much for supporting YABER!

Please read this manual thoroughly before using the projector. If you have any issues, email your order number and the problem to aftersales@yabertech.com. We will provide a fast solution in 24 hours.

Actually, many problems can be easily solved by setting, such as no signal, no sound, blueteeth connection failed, WiFi connection failed, dark spots, choppy animation etc. We promise all the projectors have been 100% carefully checked and packaged before shipping.

If you have any questions, could you please contact us so that the problem can been solved. And give us an opportunity to improve. We guarantee we will provide you a satisfactory solution.

Thanks for your understanding!

YABER Service Team

TIPS:

- 1.Do not place projector in too warm or too cold room, because the high temperature or low temperature will shorten lifespan of the device. The working environment would be $5^{\circ}\text{C}\sim35^{\circ}\text{C}$ better.
- 2.If there are black spots on the projection screen, please don't worry, please contact aftersales@yabertech.com via email, we can send you a video about how to remove the dust.
- 3. The ventilation is equipped for the projector to work stably. Don't cover the vent with cloth, blanket or other things. Don't insert anything into the slit of the projector, or it may produce a short circuit or an electric shock to your device and cause damage.
- 4. The projector shall be strictly protected from strong impact, extrusion and vibration. Do not try to move and on strong impact, extrusion and vibration. Do not try to move and the internal circuit faults.
- 5.Lens, as the core component of the projector, is directly related to the picture definition and effect. The excessive dust thereon will affect image quality. The dirty lens shall be wiped with soft cotton cloth for the glass lens surface. Hard cloth or abrasives shall not be used.


PACKAGE LIST _____

YABER Pro U9 Projector*1	Remote Control*1	Power Cord*1	
HDMI Cable*1	3-in-1 AV Cable	Lens Cover*1	
Cleaning Cloth*1	User Manual*1	Cleaning Kit*1	
Projector Screen*1			


PROJECTOR SPECIFICATIONS _____

Model No. Pro U9					
Native Resolution	1920*1080P	Keystone Correction	Manual Vertical/Horizontal		
Display Technology	LCD	Light Source	LED		
Color Gamut	16.7M Full	Aspect Ratio	4:3/16:9		
Recommended Projection Distance	8.8-14ft	Minimum Projection Distance	4.0ft		
Power Voltage	AC100-240V	Projector Weight	3.86lb		
Picture File	JPG/JPEG/ BMP/PNG	Interfaces	HDMI*2/USB*2/3.5mm Headphone jack/AV		
Projection Method	Front/Rear on Desk, Front/ Rear on Ceiling				
Video File	3GP/MP4/MPG/MKV				
Audio File	MP3/APE/AAC/FLAC/OGG/MID/M4A				

PROJECTOR OVERVIEW _




1	Foot pad	Increase the height of the projector
2	Projector lens	Optical coated glass lens
3/11	IR Window	Infrared signal receiver
4	Speakers	Speakers stereo 5w
5	USB Ports	U1 input / U2 input
6/7	HDMI Ports	HDMI 1 input / HDMI 2 input
8	Power Cord Port	Power Cord Port
9	AV Port	AV Signal Input
10	Headphone Jack	3.5mm Headphone Output
12	Vents	Prevent the projector from overheating
13	Focus Ring	Adjust the focus ring to get the clearest image
14	Keystone Ring	Adjust the keystone ring to get a rectangle shape
15	Detachable Dust Cover Switch	Use the attached screwdriver to remove the switch, then take detachable dust cover out upwards
16	Detachable Dust Cover	Clean the dust (if the screen has a black spot)
17	Bottom label	Nameplate on the bottom of the projector
18	Rubber Pads	Protective pads/remove to install ceiling mount



Tips: Pro U9 fuselage buttons are touch-screen buttons, which can be operated with a light touch.

1	Power	Turn on/off the power
2	Menu Key	Operate in AV or HDMI mode
3	OK	Confirm the option
4	Arrow Keys	Used to adjust the parameter of the projector in the menu mode
5	Source	Select the input signal soucre
6	Back	Return to the previous menu

REMOTE CONTROL =



1	Ф	Turn on/off the power
2	\Diamond	Make system settings
3	М	Can make some basic adjustments of the screen after clicking during the video playback
4	=	Operate in AV or HDMI mode
5	4 -	Volume down
6	H	Play or pause the video in USB mode
7	*2	Close the sound
8	S	Select the input signal soucre
9	· ok·	Used to adjust the parameter of the projector in the menu mode
10	⇧	Back to the main menu
11	IJ	Return to the previous menu
12	4 +	Volume up


Note:

- 1).Install 2 pieces of AAA batteries into the remote controller before using it. Do not combine new batteries with old ones in remote controller, which can cause operation failure due to insufficient power supply.
- 2). When using the remote controller, please make sure that the signal transmitter of the remote controller aims at infrared signal receiver of the projector.
- 3).If you are not using the remote controller for an extended period, please take out batteries to prevent batteries leakage.

INSTALLATION =

1. Installation Method

The projector can be hanged on the ceiling with special hanger frame, and placed on the stable desk to project the image according to the operating environment and requirements. In addition, the projector can be installed with following methods:



Keep the projector at a height where its lens is axial symmetry to the screen. If this is not possible, use the keystone correction function to adjust the projection image.

If you want to get a free projection screen, please contact us via aftersales@yabertech.com


Aspect Ratio: 16:9			
Distance (ft.) Screen Size			
4.00	37"		
5.50	52"		
7.80	78"		
10.80	108"		
13.00	132"		
16.40	166"		

The recommended projection distance is about 10.8ft,the shortest projection distance is 4.0ft.

The image size depends on the distance between projector and screen,

there may be 3% deviation among above listed data. Different settings cause various distances.

2. Install on the Ceiling



A.Please purchase an universal projector ceiling mount;

B.Remove the four rubber pads on the bottom of the projector, you will see the screw holes and use the M4*10mm screws for installing the ceiling, and then install it.

STARTING PROJECTOR


- 1)Press the power key on the remote or projector, the indicator light will turn blue;
- 2)Adjust the focus ring of the projector to get the best image performance; (If it is still blurry, please try to adjust the projection distance.)
- 3)Use the 4D keystone function of the projector to get a rectangle projection screen;
- 4)Connect the external device (Smart phone, iPad, Fire TV stick, TV box, DVD player, Computer, etc.) in the corresponding interfaces of the projector, please be sure to select the corresponding source. If you do not select the correct source, the projector will not be able to detect the signal;
- 5)Select the " (ô) " menu,enter the [Setting],then you can select the option [Language Setting] to set your preferred language.
- **PS:** Enter the [Setting] menu- then you can select the option [Language] to set the preferred language.

IMAGE ADJUSTMENT

When using the projector for the first time, it normally displays an unclear image. This is due to the lens being out of focus or the incorrect trapezoid setting.

Please follow the below steps to correct:

1. Focus Adjustment



2. Image adjustment

Please follow the below steps to correct:

Adjust the image size to get the best image size by moving the projector back and forth, then rotate the lens to get the best focus. Use the keystone ring or 4D&4P keystone function (4 Corner keystone& 4 Side) keystone of the projector to get a rectangle projection screen.

3. Select the Signal Source

Press the "S" button on the remote control or the projector and choose between: "AV", "HDMI1", "HDMI2" Connect the external device (Smart phone, iPad, Fire TV stick, TV box, DVD player, Computer, etc.) in the corresponding interfaces of the projector, please be sure to select the corresponding source. If you do not select the correct source, the projector will not be able to detect the signal. And you can see the homepage "Video" "Music" "Picture" "Signal Source""iOS Cast""Miracast".



SETTING UP THE PROJECTOR

The projector's home page is as follow.



1. Select The Input Signal Source

Select the desired input signal source (HDMI1/HDMI2/AV) on the home-page

2. USB Disk Input Mode

2.1. Play Video/Music/Picture/Office in the USB Disk Input Mode

- 1). Insert the USB Disk, Select the option [Video/Music/Picture/Office];
- 2). Select the desired file (or folder to enter the subfolder) in the USB disk, then press the [OK] button to play it.

TIPS:

A.Pro U9 upgraded projector supports U disk to directly play PPT, Word, Excel files:

B.If you enter from the [Video] menu, you can only play the video, The same as other 3 option.

2.2. Video Interface



Menu	Function
K	Switch to the previous video
«	Fast Backward,rewinds the video back quickly while playing it. The rewinding speed ranges from 2X to 32X
	Play or pause the current video
>>	Fast Forward, pushes the video to move forward quickly while playing it. The forward speed ranges from 2X to 32X
₩	Switch to the next video

Player Menu	Include	Function
Subtitle options	Subtitle On-Off,Subtitle Switching, Subtitle advanced	set multiple modes of video subtitles
Audio options	Track Switch	You can set the audio mode
Advanced options	Forward revind	You can set the video to fast forward or rewind
Screen Scale Default,Full-Screen Playback,16:9 Playback,4:3 Playback		You can set the video aspect ratio
Speed	0.25-2	Video playback multiple

2.3. Music Play Interface



- 1. Press the " := " button on the remote control ,You can directly open the music list and play directly
- 2. Press the "ス゚," button on the remote control ,You can set the music play mode, single loop/random play, etc.

2.4. Office Play Interface

Choose the file you want to open, press the "OK" button on the remote controller or projector. When you open PPT file, you can select two play modes: paly, auto play.



3. WiFi Setting

Wireless Connection


Warming Tips:

- ①The fluency of screen mirroring with wireless connection will be affected by the network environment. A bandwidth of 100Mbit or more is recommended when using screen mirroring.
- ②Make sure your mobile device is close to the projector when using wireless connection. A distance within 1 meter is recommended.
- Some mobile devices may not support screen mirroring due to the compatibility.
- Any questions, please feel free to email YABER via aftersales@yabertech.com

3.1. iOS Cast (for iOS Devices)

1.Go to home page -- Select the [] menu -- Select the [WiFi] menu

-- Open the WiFi function -- Select your home WiFi from the list -- Connect the U9 projector to your home WiFi.



2.Back to home page -- Select [iOS Cast] menu -- Press the OK button to enter the [iOS Cast] menu.



3.Select the [Settings] menu on your iOS device -- Turn on the [Wi-Fi] function -- Connect your iOS device to the same home network as the projector.

4.Open the [Control Center] on your iOS device -- Select the [Screen Mirroring] function -- Select and connect the iOS Cast receiver named [BJ_XXXXX] -- your iOS device screen will be displayed on the projection screen after 3 seconds.


3.2. Miracast (for Android Devices)

1.Go to home page -- Select the [Miracast] menu -- Press the OK button to enter the [Miracast] interface.





2.Select the [Settings] menu on your Android device -- Select the [Screen mirroring] function--Select your Miracast receiver named [Android_XXXX -- your Android device screen will be displayed on the projection screen after 3 seconds.



3.On your Android device, tap [Settings] -[WLAN Display] -Turn [Wi-Fi] ON, Connect your home WiFi.

Note:

- 1.Different brands of Android phones have different operations for select Screen Mirroring Display, please refer to your phone's manual. [Multiscreen/Wireless display/WLAN display/Screen mirroring/Wireless projection/Smart view etc.]
- 2.Not all Android phones support this function. Please make sure it is supported before use.

4. Blueteeth Setting

- (1) Go to home page -- Select the [$\langle \hat{} \rangle$] -- Select the [Blueteeth].
- (2) Open the Blueteeth function and your Blueteeth device.
- (3) Click "Search for the Blueteeth devices".
- (4) Choose the Blueteeth device desired and press OK, wait a few seconds for a successful Blueteeth connection.





Note:

- 1.The Pro U9 projector is compatible with the Blueteeth headsets, Blueteeth speakers and Airpods, but not the Blueteeth keyboards or Blueteeth phones.
- 2. When connecting a Blueteeth speaker, Need to disconnect from the previously connected device or turn off the previous Blueteeth device, make sure the speaker is waiting for pairing, Otherwise the projector cannot search for Blueteeth or cannot connect to Blueteeth speakers.
- 3. If you have any question, please feel free to email YABER via aftersales@yabertech.com

5. Image Setting

Select "(ô)" menu on the projector's home page








Image setting	Include	Function	
Picture Mode	Standard, Vivid, Soft, User	Switch among the image mode	
Brightness	0~100 Adjust the brightness parameter to		
Contrast	0~100	Adjust the contrast parameter 0-100	
Saturation	0~100	Adjust saturation parameters 0-100	
Sharpness	0~100	Adjust sharpness parameters 0-100	
Color Temperature	Standard, Warm, Cool	Adjust color temperature	
NR	Off,Low,Medium,High Noise setting		
Over scan	ON,OFF	Over scan	

6. Keystone Setting

6.1 4-corner Keystone: 0~50

When the projection screen is not rectangular, it can be adjusted by 4-point keystone correction.

Step 1: Press the button to select the [4-corner Keystone] menu, then press the [OK] bottom to enter the submenu.

Step 2: Press the OK button on the remote controller or projector to select the point.


Step 3: Press the arrow keys on the remote controller or projector to adjust the horizontal or vertical parameters, until the projection screen becomes the desired rectangle.





6.2 4-side Keystone: -40~40





Step 1: Press the button to select the [4-side Keystone] menu, then press the [OK] bottom to enter the submenu.

Step 2: If the projection image shows as (1), press the button on the remote controller or projector to increase the vertical parameter (-40~0), until to achieve the projection image (2).

Step 3: If the projection image shows as (3), then press the button on the remote controller or projector, and decrease the vertical parameter (0~40), until to achieve the projection image (4).



6.3 Reset


Click the "reset", the parameters will be restored to default values.

7. Projector Position




You can set 4 projection modes here:

- 1. Front-Celling
- 2. Rear-Celling
- 3. Front
- 4. Rear



8. Custom zoom



Step 1: Press the button to select the [Customer zoom] menu, then press the [OK] bottom to enter the submenu.

Step 2: Turn on "Custom zoom", click the "Scaling", turn on the Scaling function, you can reduce the height and width of projection size up to 50% in the same proportion.

Step 3:Click the "Scaling", turn off the Scaling, you can reduce the horiziontal ZOOM and Vertical zoom of projection size up to 50% apartly.

9. System update



10. Factory Reset




11. Language





SIGNAL LINES CONNECTION

YABER Pro U9 projector has 6 interfaces, HDMI ports*2/USB ports*2/AV in /Audio output. Please select the correct connecting port to connect your device (PC, Phone, DVD Player, Sound bar, USB, PS4 etc.)



1. Connect USB Disk

- 1). Insert the USB Disk, Select the option [Video/Music/Picture/Office];
- 2). Select the desired file (or folder to enter the subfolder) in the USB disk, then press the [OK] button to play it.

2. Connect the Devices via the HDMI ports

- 1) Connect your TV stick or laptop to any HDMI port of the projector;
- 2) Enter the home page to select the corresponding HDMI as the signal source.

3. Connect to the DVD Player

Use the 3-in -1 AV cable in the package


- 1) Turn on your DVD player and the projector;
- 2) Connect the colorful female connectors to your DVD player's RCA cable with the 3-in-1 AV cable in the package;
- 3) Connect the black connector to the AV port of the projector, enter the home page to select [AV] as the signal source.





Or connect to the DVD Player with the HDMI cable in the package.






4. Connect to the Sound bar/Speaker

If your speaker has AUX port, please use your 3.5mm audio cable connect the projector and your speaker as the picture shows.





SAFE SHUTDOWN

1. Press the button"()" on the projector or remote controller. There will be three options, restart, shut down, scheduled shut down. You can choose different shutdown modes.



- 2. Unplug the power cord of the projector.
- 3. Cover the lens and store the projector in a cool and dry place.

WARRANTY :

Thank you so much for your purchase and support! We provide 3-year warranty for Pro U9 projector. If you have any questions, please feel free to contact us via aftersales@yabertech.com

TROUBLESHOOTING .

Problems listed below might occur during the operation of your projector. Please refer to the possible factors which might cause the issue to do troubleshooting.

- 1. When turning on the power switch, the indicator light does not work.
 - 1) The power might not be connected well.
 - Check the over-heat protection system.
- 2. The remote controller does not communicate with the projector.
 - 1) The power switch at the back of the projector is turned on or off?
 - 2) The remote controller's batteries are depleted?
 - Something obstructing the signal between the remote and IR
 - 4) Strong light on IR directly.

3. No image on the screen.

- 1) Is the channel set-up correct?
- Is there an input signal ?
- 3) Is the input cable plugged well?
- 4) Under PC mode, is the refresh rate > 75KHz?
- 4. Blue screen.no picture.no sound.


Input cables connected right?

- 5. Picture right, no sound.
 - 1)Input cables connected right?
 - Volume at min or on Mute.
- 6. Can't play the movies.
 - 1)The format of the video is right?
 - 2)Files are broken?
 - 3)Device is broken?
- 7. There is picture, no sound?

The decode system doesn't match.

- Can't find devices when connected with hard drive or flash drive. Check if the device is broken.
- Auto-off after working for a while.
 - The projector ventilation is blocked.
 - 2) The voltage is not stable.
 - 3) The over-heat protection system.





FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

WARRANTY AND SERVICE

We guarantee the unit TO BE free from defects in material or workmanship for a period of one (1) year from the date of purchase. Should this unit be operated under conditions other than those recommended or at voltages other than the voltage indicated on the unit, or any attempts made to service or modify the unit, this will render WARRANTY VOID. The product you buy may sometimes differ slightly from illustration.



DISPOSAL

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Declaration of Conformity

We (Manufacturer is responsible for this declaration)

YABER TECHNOLOGIES CO.,LIMITED. (Company name)

Room 406,4 Floor,B Building,BanTian International Center,HuanCheng South Road,BanTian Street, LongGang District,Shenzhen, China (Company address)

declare under our sole responsibility that the product

Trade name: Yaber

Equipment: Entertainment Projector

Model No.: Pro U9

to which this declaration relates is in conformity with the essential requirement set out in the Council Directive on the Approximation of the laws of the Member States relating to LVD Directive(2014/35/EU) & EMC Directive(2014/30/EU) & RoHS(2011/65/EU) product is responsible to affix CE marking, the following standards were applied:

EN 62368-1:2014+A11:2017

EN IEC 62311:2020

ETSI EN 301 489-1 V2.2.3(2019-11)

ETSI EN 301 489-17 V3.2.4(2020-09)

ETSI EN 301 489-3 V2.1.1(2019-03)

EN 55032:2015+A11:2020

EN 55035:2017 +A11:2020

EN IEC 61000-3-2:2019

EN 61000-3-3:2013+A1:2019

ETSI EN 300 328 V2.2.2(2019-07)

ETSI EN 301 893 V2.1.1(2017-05)

ETSI EN 300 440 V2.2.1(2018-07)

IEC62321-3-1:2013

IEC62321-4:2013 IEC62321-5:2013

IEC62321-6:2015

IFC62321-0.2013

IEC62321-7-2:2017

IEC62321-8:2017

Full Name: George.wang Position: Approbation Manager

Signature: George.wang Place/Date: Shenzhen, China/Mar.04-2022



- www.yabertech.com
- Yaber entertainment projector
- aftersales@yabertech.com
- @Yaber.official