


BT222



.22 CALIBER BULLET BOX

Model: BT222
Instruction Manual



For .22 & .17 Rimfire

DO-ALL TRAPS, LLC DOES NOT ACCEPT ANY RESPONSIBILITY FOR DAMAGES AND/OR INTURY SUSTAINED FROM THE USE OR MISUSE OF THIS PRODUCT.

WARRANTY & CUSTOMER SERVICE

Register your product online at www.doaloutdoors.com or call customer service at 1(866)SHOT-DOC.
Receipt is required for warranty registration. ONE YEAR PARTS GUARANTY.

1(866)SHOT-DOC

customerservice@doaloutdoors.com

Monday - Friday 8:00 AM to 4:00 PM

DO-ALL OUTDOORS, LLC. NASHVILLE, TN - U.S.A.

**WARNING: TO AVOID SERIOUS INJURY, PLEASE READ
AND FOLLOW ALL INSTRUCTIONS PRIOR TO USE**




1. Carefully unbox all the parts and begin by attaching one side to the bottom as shown in the picture. Use the 6MM allen wrench (provided) to screw in the 6MM allen screws and tighten.



2. Insert hanging rod into the non-threaded hole at the tip of the first side and place the second side over the frame assembly (just like the previous side). Use the 6MM allen wrench to screw the 6MM allen screws onto the frame assembly. NOTE: It may be easier to install the side first and then place the hanging rod into the holes. They will seat better once the back is installed.

3. Place the back piece onto the frame and using the remaining 6MM allen screws, tighten the back into place with the label to the outside. Make sure the hanging rod has been installed prior to tightening.



4. Attach target bracket to the hanging rod and set the clip to hold your paper target.

FOR SOFT NOSE .22 & .17 (RIMFIRE ONLY) AND AIR GUN NON-STEEL PELLETS (NO BB'S). ALWAYS WEAR PROPER EAR AND EYE PROTECTION. ALWAYS KNOW WHAT IS BEYOND YOUR TARGET AND BE SURE TO MAINTAIN THE PROPER BACKDROP WHEN SHOOTING TO PREVENT INJURY FROM MISDIRECTED OR RICOCHED PROJECTILES. ADULT SUPERVISION REQUIRED FOR CHILDREN UNDER 18 YEARS OLD.