Vibratory Power Screed Troubleshooting Manual





For issues with Recoil Starter, Pressure Build Up, Flooded Engine, & Smoke




If your screed has difficulty starting or excess engine smoke, your engine may be flooded.







Test the plug by touching it to the metal cylinder & pull the recoil starter several times.



Remove the engine's spark plug with a spark plug wrench.



If the plug sparks, reinstall. If the plug does not spark, dry off and pull again, until you see a spark. If the spark plug will not spark, replace the spark plug.