



[www.tomahawk-power.com](http://www.tomahawk-power.com)

# Concrete Scarifier Assembly Manual **TSCAR-8H**





www.tomahawk-power.com

# Concrete Scarifier Assembly Manual **TSCAR-8H**

## Table of Contents

Table of Contents	2
Suggest Tools	2
Handle Assembly	3-4
Drum Replacement Assembly	5

## Suggested Tools for Assembly

### **TOOL**

5/16 Allen Key

26mm Socket

26mm Wrench

### **USED ON**

Handle Assembly

Drum Assembly

Drum Assembly

# Concrete Scarifier Handle Assembly Pt. 1



**1** Remove the scarifier's engine and handles from their packaging.



**2** Using a 5/16 Allen Wrench, unscrew the bolts from the machine's housing.




**3** Lean the engine forward and fasten the handle to the machine's housing.



**4** Unwind the kill-switch wire from around the machine's handle.



**5** Thread the kill-switch line between the bottom frame of the machine's housing.



**6** Bring the kill-switch wire to the On/Off Switch on the left of the engine.




# Concrete Scarifier Handle Assembly Pt. 2




**1** Pull back the black plastic clip to find the engine wire.



**2** Unplug the upper black engine wire.



**3** Plug in the kill switch wire to the black engine wire.



**4** Bundle the wires and clip together with the black plastic clip.



**5** Your concrete scarifier is now ready for use.

# Concrete Scarifier Drum Install/Replacement



**1** Tilt the machine forward.



**2** Use a 26mm socket and a wrench to remove the drum bar under the housing.



**3** Twist bar in clockwise motion (reverse thread) to loosen. (Remove old drum if replacing).



**4** Place new drum inside the machine's housing.



**5** Push the bar through the drum to the outside of the machine's housing.



**6** Twist the bar in a counterclockwise direction to tighten (reverse thread).

# TOMAHAWK

Tomahawk Power, LLC  
San Diego, CA

## **Sales Support**

(866) 577-4476

[sales@tomahawk-power.com](mailto:sales@tomahawk-power.com)

## **Service and Registration**

[support@tomahawk-power.com](mailto:support@tomahawk-power.com)

[www.tomahawk-power.com](http://www.tomahawk-power.com)