



# ISLAND BLENDER

## INSTALLATION INSTRUCTIONS & OWNER'S MANUAL



**INSTALLER:** Leave these instructions with consumer.  
**CONSUMER:** Retain for future reference.

**IMPORTANT:** READ ALL INSTRUCTIONS, INCLUDING THE INSTRUCTIONS PROVIDED WITH YOUR BLENDER, CAREFULLY BEFORE STARTING INSTALLATION OR OPERATION.

Table 1 - Model Specifications Table

Specification	Value
Counter opening width	8-3/4" (21 cm)
Counter opening depth	14-1/4" (35.8 cm)
Vert. clearance below counter*	4" (15.2 cm)
Vert. clearance above counter*	25" (63.3 cm)

\* minimum dimension

Blender



Countertop blender housing

