



Twin Eagles Charcoal Tray (TECT)

Instruction Sheet

Warning: This tray is intended to be used on Twin Eagles product only. Do not touch or remove the tray while the coals are lit. The metal parts will be hot. Do not dispose of the coals or ash while the coals are hot. After the tray has cooled down, the ash may be disposed of in a fireproof container.



Step 1: Remove grate and briquette tray from the area to be cooked on. **Note: The Charcoal Tray is not intended to be used over the Sear burner.**



Step 2: Insert Charcoal Tray into desired location.



Step 3: Add a single layer of coals to the tray.



Step 4: Use a spatula to move grate into cooking position or to uncover the coals. Cover the coals with the grate before the ignition to preheat the grate.



Twin Eagles Charcoal Tray (TECT)

Instruction Sheet

Note: While cooking with the Charcoal Tray, all normal safety precautions should be followed. Please refer to your Twin Eagles Use & Care manual for all safety cautions, warnings, and instructions.



Step 5: Turn on grill burner to high setting to ignite coals. (See Twin Eagles Owner's Manual for proper lighting instructions.)



Step 6: When the coals begin to turn white, turn off the grill burner. Depending on the coal used, this could take up to 5 minutes. **Note: Quick-light coal or lighter fluid is not necessary for this tray.**



Step 7: To add coals, easily move the grate with the spatula. Then add the coals to the tray.



Step 8: Move the grate back into cooking position. Allow the new coals to turn white before cooking.