

## **KYOWA SERVICE CENTER (MAIN)**

RM. 1203, STATE CENTER BLDG, #333 JUAN LUNA ST, BINONDO MANILA  
TEL: 242-1731 - 35

### **METRO MANILA**

**TRONIX QUEZON CITY (MAIN)** #777 N.S. AMORANTO ST, COR. STO. DOMINGO AVE, Q.C.  
TEL: 743-9094 / 749-8477 MOBILE: 0922-8534797/0917-5231489 CONTACT PERSON: MS. JENIELYN  
MANZANO

**TRONIX MANILA** #1793 CONCEPCION AGUILA ST, NEAR J.P. LAUREL ST, SAN MIGUEL, MANILA  
(NEAR  
MALACANANG)  
TEL: 743-4088 MOBILE: 0922-7909555 CONTACT PERSON: MS. ANALEN FIADACAN

**TRONIX STA. CRUZ** #910 LUZON ST. (BET. MASANGKAY & BENAVIDEZ ST.) STA. CRUZ, MANILA  
TEL: 542-8345 / 310-3553 MOBILE: 0922-2389971 CONTACT PERSON: MS. SHEILA PIRANTE

**TRONIX SAN JUAN** #135 N.DOMINGO ST, CORNER PINAGLABANAN, BRGY. BALONG BATO, SAN  
JUAN CITY  
TEL: 949-3608 / 984-6395 MOBILE: 0922-9218653 CONTACT PERSON: MS. MICHELLE CASAÑA

**TRONIX ALABANG TOWN CENTER** LA-7 SERVICE TOWN, ALABANG TOWN CENTER, MUNTINLUPA  
CITY  
TEL: 807-3546 / 624-6880 MOBILE: 0922-7584917 / 0917-5899059 CONTACT PERSON: MR. FRANCIS  
ACOSTA / MS. MEAN

**TRONIX PARAÑAQUE** #103 CMSR BLDG, PHASE 1, 88 PRESIDENT AVENUE, BF HOME, PARAÑAQUE  
TEL: 622-4540 / 861-0092 / 828-2915 MOBILE: 0917-5978342 / 0932-4060806 CONTACT PERSON: MS.  
ELIZABETH PALIMA

**TRONIX MAKATI** #103 MJM BLDG, 650 JP RIZAL ST, BRGY. VALENZUELA MAKATI CITY  
TEL: 710-1980 / 949-3684 MOBILE: 0932-1999085

**TRONIX MARIKINA** #572 J.P. RIZAL AVE, CONCEPCION 1, MARIKINA (IN FRONT OF KSERVICO)  
TEL: 696-6411 MOBILE: 0942-0940088

**TRONIX PASIG** LOWER GROUND SERVICE LANE, SM CENTER, PASIG  
TEL: 703-5599 / 234-9020 MOBILE: 0932-1999372 CONTACT PERSON: MS. NORA CRESENCIO

**TRONIX SHAW - MANDALUYONG** #412 SHAW BLVD, COR. TORRES & CALDERON ST,  
MANDALUYONG CITY  
TEL: 542-8360 / 725-7290 MOBILE: 0923-1646350 CONTACT PERSON: MS. SHERLY DELA CRUZ

**TRONIX COMMONWEALTH** LAGMANLAG COMMONWEALTH AVE, HOLY SPIRIT, DILIMAN, Q.C.  
(BESIDE SHELL)  
TEL: 623-7266 MOBILE: 0933-6584465 / 09175810546 CONTACT PERSON: MR. MANNY SAGAYAP

### **CAVITE**

**TRONIX CAVITE** KM 16, AGUINALDO HI-WAY, NIOG 1-A, PANAPAAN 1, BACOR, CAVITE  
TEL: (046) 519-0755 / (046) 475-6362 MOBILE: 0932-1991811 CONTACT PERSON: MS. MEANN

### **CEBU**

**MARKWELL ENTERPRISES** #85 SIKATUNA ST, CEBU CITY  
TEL: (032) 253-0752 MOBILE: 0917-6256934 CONTACT PERSON: MR. BOY SOUICO

**BIO PLUS ELEC. REPAIR CENTER** C. PADILLA ST, SAN ROQUE, MAMBALING, CEBU CITY  
TEL: (032) 262-1339 MOBILE: 0922-4744991 CONTACT PERSON: MS. ZYSELDA MABUTE

### **DAVAO**

**KOOL EXPRESS** DOOR 5, LUA BLDG, QUIRINO AVE, DAVAO CITY  
TEL: (082) 227-6369 MOBILE: 0908-420-6303 CONTACT PERSON: MS. DORIS ASIRIT

### **ILOILO**

**NACES APPLIANCE CORPORATION** NACES BLDG, #10 DELGADO ST, ILOILO  
TEL: (033) 337-7696 MOBILE: (033) 508-2205 CONTACT PERSON: MS. LORELIE LIM

### **TARLAC**

**TARLAC MAC ENTERPRISES INC.** BLK. 9, MCARTHUR HIGHWAY, SAN NICOLAS, TARLAC  
TEL: (045) 982-3178 MOBILE: 0922-8597136



# FLAT IRON

MODEL # KW-7002

Voltage: 230V a.c. 60Hz Power: 1100 WATTS




## INSTRUCTION MANUAL

## CONGRATULATIONS

You are now a proud new owner of a KYOWA Flat Iron model no. KW-7002.

Before using for the first time, kindly take time to carefully read your instruction manual. Please observe all safety precautions and follow operating procedures. After reading, kindly store your instruction manual in a safe place for your future reference. Should you pass on this Flat Iron to a third party, please hand over this instruction manual as well.

## PARTS DESCRIPTION



## IMPORTANT SAFEGUARDS

When using your Flat Iron, basic safety precautions should always be followed:

- Always operate your KYOWA Flat Iron from a power source of the same voltage and frequency rating as indicated on the rating label.
- Do not let the power cord hang over the edge of counter or table.
- Do not operate or place any part of your KYOWA Flat Iron on or near any hot surface such as gas or electric burner, hotplate or heated oven.
- Do not operate iron with a damaged cord or if the iron has been dropped or damaged.
- Do not disassemble the iron. Take it to a qualified serviceman for examination and repair. Incorrect reassembly may cause a risk of electric shock when the iron is in use.
- The iron should always be turned to the lowest setting before plugging or unplugging from outlet.
- Do not allow cord to touch hot surface. Let iron cool down completely before putting away. Loop cord loosely around iron when storing.
- Do not leave iron unattended while connected or in an ironing board. Burns may occur from touching hot metal parts, hot water or steam.
- Avoid touching hot surfaces of the iron during use. Use the handle only.
- Switch off and unplug the iron when not in use.
- The iron must be used and rested on a stable surface
- When placing the iron on the stand, ensure that the surface on which the stand is placed is stable
- To reduce the risk of electric shock, do not immerse or expose the Flat Iron to rain, moisture or any liquid.
- Keep out of reach from children or from persons with mental or physical disabilities.
- Children should be supervised to ensure that they do not play with the appliance.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- This KYOWA Flat Iron is intended for normal domestic/household use only. This unit is not suitable for commercial use.

## HOW TO USE

- Some parts of the iron have been slightly greased and as a result, the iron might slightly emit smoke when connected for the first time. This however, will cease after you have used the iron for some time.
- Classify clothing material according to labels indicated on the dial before use. Refer to Fabric Guide under handle for suggested heat settings.
- The iron heats up faster than it cools down so it is recommended to begin ironing the clothes which require lower ironing temperature (synthetic fibre, fabric and silk), than clothes of other materials requiring higher temperature (wool, cotton, jute, and etc.).
- Rest the iron vertically and set the Temperature Control Dial at "MIN" setting.
- Insert the plug into the socket, turn the Temperature Control Dial to the temperature point required by the clothing material and aim the material identity mark at the Heating Indicator. You may start ironing when the Indicator Light turns off.
- Try to iron an old piece of cloth first to check the heating level of the iron.

## CLEAN AND CARE

- Turn the Temperature Control Dial to "MIN" setting and then unplug from the outlet. Allow the iron to cool down completely before putting away.
- When removing the cord from the outlet, grasp the plug rather than pulling the cord.
- Avoid ironing over zippers or rivets on jeans for this may scratch the soleplate.
- Never use abrasive cleaning agents or any metallic and sharp objects (e.g. scrubbing brush or knife) for cleaning.

## SERVICE

- Do not operate your KYOWA Flat Iron if the unit malfunctions or appears damaged in any manner. Bring the complete product to the place of purchase or to any authorized KYOWA dealers for inspection, repair or replacement.
- Do not disassemble the Flat Iron by yourself. No user serviceable parts inside. Refer all service to an authorized KYOWA service facility ONLY.