

KYOWA SERVICE CENTER (MAIN)

RM. 1203, STATE CENTER BLDG, #333 JUAN LUNA ST, BINONDO MANILA
TEL: 242-1731 - 35

METRO MANILA

TRONIX QUEZON CITY (MAIN) #777 N.S. AMORANTO ST, COR. STO. DOMINGO AVE, Q.C.
TEL: 743-9094 / 749-8477 MOBILE: 0922-8534797/0917-5231489 CONTACT PERSON: MS. JENIELYN MANZANO

TRONIX MANILA #1793 CONCEPCION AGUILA ST, NEAR J.P. LAUREL ST, SAN MIGUEL, MANILA (NEAR MALACAÑANG)
TEL: 743-4088 MOBILE: 0922-7909555 CONTACT PERSON: MS. ANALEN FIADACAN

TRONIX STA. CRUZ #910 LUZON ST. (BET. MASANGKAY & BENAVIDEZ ST.) STA. CRUZ, MANILA
TEL: 542-8345 / 310-3553 MOBILE: 0922-2389971 CONTACT PERSON: MS. SHEILA PIRANTE

TRONIX SAN JUAN #135 N.DOMINGO ST, CORNER PINAGLABANAN, BRGY. BALONG BATO, SAN JUAN CITY
TEL: 949-3608 / 984-6395 MOBILE: 0922-9218653 CONTACT PERSON: MS. MICHELLE CASAÑA

TRONIX ALABANG TOWN CENTER LA-7 SERVICE TOWN, ALABANG TOWN CENTER, MUNTINLUPA CITY
TEL: 807-3546 / 624-6880 MOBILE: 0922-7584917 / 0917-5899059 CONTACT PERSON: MR. FRANCIS ACOSTA

TRONIX PARAÑAQUE #103 CMSR BLDG, PHASE 1, 88 PRESIDENT AVENUE, BF HOME, PARAÑAQUE
TEL: 622-4540 / 861-0092 / 828-2915 MOBILE: 0917-5978342 / 0932-4060806 CONTACT PERSON: MS. ELIZABETH PALIMA

TRONIX MAKATI #103 MJM BLDG, 650 JP RIZAL ST, BRGY. VALENZUELA MAKATI CITY
TEL: 710-1980 / 949-3684 MOBILE: 0932-1999085

TRONIX MARIKINA #572 J.P. RIZAL AVE, CONCEPCION 1, MARIKINA (IN FRONT OF KSERVICO)
TEL: 696-6411 MOBILE: 0942-0940088

TRONIX PASIG LOWER GROUND SERVICE LANE, SM CENTER, PASIG
TEL: 703-5599 / 234-9020 MOBILE: 0932-1999372 CONTACT PERSON: MS. NORA CRESENCIO

TRONIX SHAW - MANDALUYONG #412 SHAW BLVD, COR. TORRES & CALDERON ST, MANDALUYONG CITY
TEL: 542-8360 / 725-7290 MOBILE: 0923-1646350 CONTACT PERSON: MS. SHERLY DELA CRUZ

TRONIX COMMONWEALTH LAGMANLAG COMMONWEALTH AVE, HOLY SPIRIT, DILIMAN, Q.C. (BESIDE SHELL)
TEL: 623-7266 MOBILE: 0933-6584465 / 09175810546 CONTACT PERSON: MR. MANNY SAGAYAP

CAVITE

TRONIX CAVITE KM 16, AGUINALDO HI-WAY, NIOG 1-A, PANAPAAN 1, BACOR, CAVITE
TEL: (046) 519-0755 / (046) 475-6362 MOBILE: 0932-1991811 CONTACT PERSON: MS. MEANN DIONISIO

CEBU

MARKWELL ENTERPRISES #85 SIKATUNA ST, CEBU CITY
TEL: (032) 253-0752 MOBILE: 0917-6256934 CONTACT PERSON: MR. BOY SOUICO

BIO PLUS ELEC. REPAIR CENTER C. PADILLA ST, SAN ROQUE, MAMBALING, CEBU CITY
TEL: (032) 262-1339 MOBILE: 0922-4744991 CONTACT PERSON: MS. ZYSELDA MABUTE

DAVAO

KOOL EXPRESS DOOR 5, LUA BLDG, QUIRINO AVE, DAVAO CITY
TEL: (082) 227-6369 MOBILE: 0908-420-6303 CONTACT PERSON: MS. DORIS ASIRIT

ILOILO

NACES APPLIANCE CORPORATION NACES BLDG, #10 DELGADO ST, ILOILO
TEL: (033) 337-7696 MOBILE: (033) 508-2205 CONTACT PERSON: MS. LORELIE LIM

TARLAC

TARLAC MAC ENTERPRISES INC. BLK. 9, MCARTHUR HIGHWAY, SAN NICOLAS, TARLAC
TEL: (045) 982-3178 MOBILE: 0922-8597136



FLAT IRON

MODEL NO.: KW-7015

Voltage: 230V a.c. 60Hz Power: 1100 WATTS




INSTRUCTION MANUAL

CONGRATULATIONS

You are now a proud new owner of a KYOWA Flat Iron model no. KW-7015.

Before using for the first time, kindly take time to carefully read your instruction manual. Please observe all safety precautions and follow operating procedures. After reading, kindly store your instruction manual in a safe place for your future reference. Should you pass on this Flat Iron to a third party, please hand over this instruction manual as well.

PARTS DESCRIPTION



IMPORTANT SAFEGUARDS

When using your Kyowa Flat Iron, basic safety precautions should always be followed:

- Always operate your KYOWA Flat Iron from a power source of the same voltage and frequency rating as indicated on the rating label.
- Do not let the power cord hang over the edge of counter or table.
- Do not operate or place any part of your KYOWA Flat Iron on or near any hot surface such as gas or electric burner, hotplate or heated oven.
- Do not operate iron with a damaged cord or if the iron has been dropped or damaged.
- Do not disassemble the iron. Take it to a qualified serviceman for examination and repair. Incorrect reassembly may cause a risk of electric shock when the iron is in use.
- The iron should always be turned to the lowest setting before plugging or unplugging from outlet.
- Do not allow cord to touch hot surface. Let iron cool down completely before putting away. Loop cord loosely around iron when storing.
- Do not leave iron unattended while connected or in an ironing board. Burns may occur from touching hot metal parts.
- Avoid touching hot surfaces of the iron during use. Use the handle only.
- Switch OFF and unplug the iron when not in use.
- To reduce the risk of electric shock, do not immerse or expose the Flat Iron to rain, moisture or any liquid.
- Keep out of reach from children or from persons with mental or physical disabilities.
- This KYOWA Flat Iron is intended for normal domestic/household use only. This model is not suitable for commercial use.

HOW TO USE

- Before using for the first time, check if the voltage rating on the base plate corresponds to the power outlet in your home.
- Remove all packing materials.
- Clean the iron surface.
- Some parts of the iron have been slightly greased and as a result, the iron might slightly emit smoke when connected for the first time. This however, will cease after you have used the iron for some time.
- The iron heats up faster than it cools down so it is recommended to first begin ironing the clothes which require lower ironing temperature (synthetic fibre, fabric and silk), then iron the clothes of other materials requiring higher temperature (woollen, cotton, jute, and etc.).
- Place the iron vertically and set the Temperature Control Dial at "MIN" setting.
- Insert the power plug in suitable socket and set the Temperature Control Dial on maximum temperature setting, the Indicator Light will light up. Wait until the Indicator Light goes off – that indicates that your iron unit is ready to use. Try to iron an old piece of cloth to check and adjust the heating level of the iron.

SETTING THE TEMPERATURE

- Turn the Temperature Control Dial to the position according to the following markings:



- SYNTHETIC SILK
- WOOL
- COTTON - LINEN

CLEAN AND CARE

- Turn the Temperature Control Dial to "MIN" setting and then unplug from the outlet. Allow the iron to cool completely before putting away.
- When removing the cord from the outlet, grasp the plug rather than pulling the cord.
- Avoid ironing over zippers or rivets on jeans for this may scratch the soleplate.
- Never use abrasive cleaning agents or any metallic and sharp objects (e.g. scrubbing brush or knife) for cleaning.

SERVICE

- Do not operate your KYOWA Flat Iron if the unit malfunctions or appears damaged in any manner. Bring the complete product to the place of purchase or to any authorized KYOWA dealers for inspection, repair or replacement.
- Do not disassemble your KYOWA Flat Iron by yourself. No user serviceable parts inside. Refer all needed repair to an authorized KYOWA service facility ONLY.