

## **KYOWA SERVICE CENTER (MAIN)**

RM. 1203, STATE CENTER BLDG, #333 JUAN LUNA ST, BINONDO MANILA  
TEL: 242-1731 - 35

### **METRO MANILA**

**TRONIX QUEZON CITY (MAIN)** #777 N.S. AMORANTO ST, COR. STO. DOMINGO AVE, Q.C.  
TEL: 743-9094 / 749-8477 MOBILE: 0922-8534797/0917-5231489 CONTACT PERSON: MS. JENIELYN MANZANO

**TRONIX MANILA** #1793 CONCEPCION AGUILA ST, NEAR J.P. LAUREL ST, SAN MIGUEL, MANILA (NEAR MALACANANG)  
TEL: 743-4088 MOBILE: 0922-7909555 CONTACT PERSON: MS. ANALEN FIADACAN

**TRONIX STA. CRUZ** #910 LUZON ST. (BET. MASANGKAY & BENAVIDEZ ST.) STA. CRUZ, MANILA  
TEL: 542-8345 / 310-3553 MOBILE: 0922-2389971 CONTACT PERSON: MS. SHEILA PIRANTE

**TRONIX SAN JUAN** #135 N.DOMINGO ST, CORNER PINAGLABANAN, BRGY. BALONG BATO, SAN JUAN CITY  
TEL: 949-3608 / 984-6395 MOBILE: 0922-9218653 CONTACT PERSON: MS. MICHELLE CASAÑA

**TRONIX ALABANG TOWN CENTER** LA-7 SERVICE TOWN, ALABANG TOWN CENTER, MUNTINLUPA CITY  
TEL: 807-3546 / 624-6880 MOBILE: 0922-7584917 / 0917-5899059 CONTACT PERSON: MR. FRANCIS ACOSTA

**TRONIX PARAÑAQUE** #103 CMSR BLDG, PHASE 1, 88 PRESIDENT AVENUE, BF HOME, PARAÑAQUE  
TEL: 622-4540 / 861-0092 / 828-2915 MOBILE: 0917-5978342 / 0932-4060806 CONTACT PERSON: MS. ELIZABETH PALIMA

**TRONIX MAKATI** #103 MJM BLDG, 650 JP RIZAL ST, BRGY. VALENZUELA MAKATI CITY  
TEL: 710-1980 / 949-3684 MOBILE: 0932-1999085

**TRONIX MARIKINA** #572 J.P. RIZAL AVE, CONCEPCION 1, MARIKINA (IN FRONT OF KSERVICO)  
TEL: 696-6411 MOBILE: 0942-0940088

**TRONIX PASIG** LOWER GROUND SERVICE LANE, SM CENTER, PASIG  
TEL: 703-5599 / 234-9020 MOBILE: 0932-1999372 CONTACT PERSON: MS. NORA CRESENCIO

**TRONIX SHAW - MANDALUYONG** #412 SHAW BLVD, COR. TORRES & CALDERON ST, MANDALUYONG CITY  
TEL: 542-8360 / 725-7290 MOBILE: 0923-1646350 CONTACT PERSON: MS. SHERLY DELA CRUZ

**TRONIX COMMONWEALTH** LAGMANLAG COMMONWEALTH AVE, HOLY SPIRIT, DILIMAN, Q.C. (BESIDE SHELL)  
TEL: 623-7266 MOBILE: 0933-6584465 / 09175810546 CONTACT PERSON: MR. MANNY SAGAYAP

### **CAVITE**

**TRONIX CAVITE** KM 16, AGUINALDO HI-WAY, NIOG 1-A, PANAPAAN 1, BACOR, CAVITE  
TEL: (046) 519-0755 / (046) 475-6362 MOBILE: 0932-1991811 CONTACT PERSON: MS. MEANN DIONISIO

### **CEBU**

**MARKWELL ENTERPRISES** #85 SIKATUNA ST, CEBU CITY  
TEL: (032) 253-0752 MOBILE: 0917-6256934 CONTACT PERSON: MR. BOY SOUICO

**BIO PLUS ELEC. REPAIR CENTER** C. PADILLA ST, SAN ROQUE, MAMBALING, CEBU CITY  
TEL: (032) 262-1339 MOBILE: 0922-4744991 CONTACT PERSON: MS. ZYSELDA MABUTE

### **DAVAO**

**KOOL EXPRESS** DOOR 5, LUA BLDG, QUIRINO AVE, DAVAO CITY  
TEL: (082) 227-6369 MOBILE: 0908-420-6303 CONTACT PERSON: MS. DORIS ASIRIT

### **ILOILO**

**NACES APPLIANCE CORPORATION** NACES BLDG, #10 DELGADO ST, ILOILO  
TEL: (033) 337-7696 MOBILE: (033) 508-2205 CONTACT PERSON: MS. LORELIE LIM

### **TARLAC**

**TARLAC MAC ENTERPRISES INC.** BLK. 9, MCARTHUR HIGHWAY, SAN NICOLAS, TARLAC  
TEL: (045) 982-3178 MOBILE: 0922-8597136



# RECHARGEABLE LANTERN

MODEL NO. KW-9107

Input Voltage: \_\_\_\_\_

Output Voltage: \_\_\_\_\_




## INSTRUCTION MANUAL

## CONGRATULATIONS

You are now a proud new owner of a KYOWA Rechargeable Lantern model no. KW-9107.

Before using for the first time, kindly take time to carefully read your instruction manual. Please observe all safety precautions and follow operating procedures. After reading, kindly store your instruction manual in a safe place for your future reference. Should you pass on this Rechargeable Lantern to a third party, please hand over this instruction manual as well.

## PARTS DESCRIPTION



## IMPORTANT SAFEGUARDS

When using your Rechargeable Lantern, basic safety precautions should always be followed:

- Always operate your KYOWA Rechargeable Lantern from a power source of the same voltage and frequency rating as indicated on the rating label.
- Connect the lantern only to properly wired wall outlets.
- Place the Rechargeable Lantern on a flat surface and far from the edge of the counter top.
- Do not operate the lantern if any part of it has been damaged. Return the appliance to the nearest authorized dealer or service facility for repair.
- Do not operate or place any part of your Rechargeable Lantern on or near any hot surface such as a gas or electric burner, hotplate or heated oven.
- Do not use or replace accessories of the Rechargeable Lantern, other than the ones originally provided.
- Switch OFF and unplug the lantern when not in use or before cleaning.
- Always hold plug of the Rechargeable Lantern when unplugging from socket. Do not unplug by pulling the supply cord.
- Do not tie power plug around the Rechargeable Lantern.
- Recharge lantern unit at least every three months to prolong battery life.
- To reduce the risk of electric shock, do not immerse or expose the Rechargeable Lantern to rain, moisture or any liquid.

## HOW TO USE

### HOW TO OPERATE THE LAMP AS EMERGENCY LIGHT

- Plug Rechargeable Lantern into the power outlet.
- Slide power switch to ON position.
- The Rechargeable Lantern will then light ON automatically when there is a power failure.
- Turn unit to OFF when not in use or if the lantern is not intended to be used as emergency light.

### HOW TO RECHARGE THE LAMP

- Plug Rechargeable Lantern into the power outlet, red indicator lamp will light up to indicate that the unit is charging.
- For initial use, recharge lantern for 24 hours.
- For subsequent charging, recharge lantern for 18 to 20 hours until battery is fully charged or until red indicator light turns OFF and green indicator light turns ON.

### HOW TO USE THE LAMP AS MOBILE CHARGER

- Disconnect power cord and plug from the rechargeable unit.  
(Note: Mobile charging capability will not work if the lantern power cord is connected to the unit.)
- Connect usb cable charger into the rechargeable lantern then connect the other end of the cable into the mobile phone unit.

## CLEAN AND CARE

- Wipe Rechargeable Lantern thoroughly with a soft and damp cloth.
- Pat dry using a soft and dry cloth.
- Never use abrasive cleaning agents or any metallic and sharp objects (e.g. scrubbing brush or knife) for cleaning.
- Avoid any kind of moisture to seep into your Rechargeable Lantern.
- Fully charged battery will eventually lose its charge if unused for a prolonged period of time. Recharge lantern unit once every 2 months to maintain good battery life.
- Store lantern in a cool and dry place after cleaning.

## SERVICE

- Do not operate your KYOWA Rechargeable Lantern if the unit malfunctions or appears damaged in any manner. Bring the complete product to the place of purchase or to any authorized KYOWA dealers for inspection, repair or replacement.
- Do not disassemble your KYOWA Rechargeable Lantern by yourself. No user serviceable parts inside. Refer all needed repair to an authorized KYOWA service facility ONLY.