

KYOWA SERVICE CENTER

Rm. 1203 State Center Building
#333 Juan Luna St., Binondo
Manila, Philippines



RECHARGEABLE FLASHLIGHT

MODEL NO: KW-9148

Input Voltage: 230V a.c. 60Hz

Output Voltage: 4V



INSTRUCTION MANUAL

CONGRATULATIONS

You are now a proud new owner of a KYOWA Rechargeable Flashlight model no. KW-9148.

Before using for the first time, kindly take time to carefully read your instruction manual. Please observe all safety precautions and follow operating procedures. After reading, kindly store your instruction manual in a safe place for your future reference. Should you pass on this Rechargeable Flashlight to a third party, please hand over this instruction manual as well.

PARTS DESCRIPTION



IMPORTANT SAFEGUARDS

When using your Rechargeable Flashlight, basic safety precautions should always be followed:

- Always operate your KYOWA Rechargeable Flashlight from a power source of the same voltage and frequency rating as indicated on the rating label.
- Connect the flashlight only to properly wired wall outlets.
- Place the Rechargeable Flashlight on a flat surface and far from the edge of the counter top.
- Do not operate the flashlight if any part of it has been damaged. Return the appliance to the nearest authorized dealer or service facility for repair.
- Do not operate or place any part of your Rechargeable Flashlight on or near any hot surface such as a gas or electric burner, hotplate or heated oven.
- Do not use or replace accessories of the Rechargeable Flashlight, other than the ones originally provided.
- Switch OFF and unplug the flashlight when not in use or before cleaning.
- Always hold plug of the Rechargeable Flashlight when unplugging from socket. Do not unplug by pulling the supply cord.
- Do not tie power plug around the Rechargeable Flashlight.
- Recharge flashlight unit at least every three months to prolong battery life.
- To reduce the risk of electric shock, do not immerse or expose the Rechargeable Flashlight to rain, moisture or any liquid.

HOW TO USE

HOW TO RECHARGE THE FLASHLIGHT

- Plug Rechargeable Flashlight into the power outlet, red indicator flashlight will light up to indicate that the unit is charging.
- For initial use, recharge flashlight for 24 hours.
- For subsequent charging, recharge flashlight for 18 to 20 hours or until battery is fully charged.

CLEAN AND CARE

- Wipe Rechargeable Flashlight thoroughly with a soft and damp cloth.
- Pat dry using a soft and dry cloth.
- Never use abrasive cleaning agents or any metallic and sharp objects (e.g. scrubbing brush or knife) for cleaning.
- Avoid any kind of moisture to seep into your Rechargeable Flashlight.
- Store flashlight in a cool and dry place after cleaning.

SERVICE

- Do not operate your KYOWA Rechargeable Flashlight if the unit malfunctions or appears damaged in any manner. Bring the complete product to the place of purchase or to any authorized KYOWA dealers for inspection, repair or replacement.
- Do not disassemble your KYOWA Rechargeable Flashlight by yourself. No user serviceable parts inside. Refer all needed repair to an authorized KYOWA service facility ONLY.