

Cell Phone Scan

Scan the QR Code. This will take you to our website, where you'll find additional information and helpful videos.

65'

Package content; 1 Hanger bag, 65' cord, 1 brass ring, instructions The Hanger is available in fluorescent orange and black

THE LITTLE BAG WITH A BIG JOB

A must have for any adventure that puts you in bear country or simply to assist in game processing, hanging clothes or for shelter.

All information was created based on personal lower 48 adventures and annual month-long Alaska excursions.

Although the odds are slim that a bear will ever attempt to make claim to your food or toiletries, it's that one time that could put you in a dangerous situation with no food. Preventing this does take effort, the alternative is well worth it.

Keep in mind that if contact with a bear occurs, you may be subject to extreme fines and possibly debilitating harm or death.

WARNING


Not intended for climbing or supporting live weight. Watch for falling objects. For safety, check knots & cord. Adult supervision required. Keep out of reach of children.



Coexisting with nature presents great challenges. One such challenge is keeping food and scented items out of reach of predators. This can be frustrating and time consuming, but it is necessary, and possibly required by law. State parks may require bear canisters, or hanging food bags out of reach of bears.


The hanger was designed to make a very difficult and time consuming procedure easier. Trying to throw a rock or branch with an attached cord can be trying. Or using a delicate nylon bag with paracord that can easily get caught and tear or hit the ground creating a hole. The paracord, although strong, is not designed for this use simply because paracord flattens causing added friction.

The Hanger was created after endless attempts at finding the right balance of cord length and bag weight. This combination allows a person to dispense the complete 65' of cord in a single throw. Our proprietary cord was made to become dense and round the harder it's pulled. This allows for easy, friction free dispensing.



Distance from tree to tree approx 12'

Hang your bags approx 50 yards from tent. Distance from tree to bags 6' and 10' to 15' up. The hanger can be thrown under it's own weight. If vertical height is needed, add a rock, sand or dirt. To feed 1/2 inch rope through trees, tie to the end of hanger cord.



Note: This device is not to be used for climbing or supporting any person or persons. Cord and cord knots must always be checked for safety...never put yourself in harms way during the use of this device. Authorized dealers and manufacturer cannot be held liable for misuse or accidents.

Note

Not all geographical landscapes are alike. With this in mind, a person should remain flexible with any of the diagram systems shown. There can be a countless number of trees, tree sizes and configurations. Or trees with branches nearly angled straight down or on the other hand no trees at all. For additional information on this subject vist our website.

Instructions

How to reload your hanger

Before using the hanger for the first time take note on how it's pre-loaded.

Method #1- Reload by pinching (hold) the throw bag between your index finger and middle finger. With the other hand, using your index finger and thumb, feed (pinch) the cord into the bag. Be sure to stop periodically and stuff the cord to the bottom.

Method #2- If you miss your target on the first throw, rather than reloading in method #1, lay a jacket or tarp flat on the ground. Now freely coil the cord making sure that each coil is laying on top of the other. Next place a rock, sand or dirt in the throw bag.

Method #3- Place a rock, sand or dirt in the throw bag. Take the brass ring and feed the cord through the ring, making a loop.

Place this around your wrist. Next, coil the cord in the non-throwing hand making about two-foot loops. Gradually shorten the

length until none of the cord will reach the ground when your arms are up in the throwing position.

Maintenance: If bag is wet allow to dry for a few days. The bag does allow moisture to escape. Allow bag and cord to completely dry before storing. Check cord knots making sure they're tight and that cord is not cut or fraying.

The hanger is designed to offer many years of confident use. We are currently working on "How To" videos.

Periodically check our website for updated information.



For additional helpful information on product use or gear visit our website or scan the QR code on the back of the page.

www.KoyukonGear.com



KOYUKON GEAR PARKER, COLORADO 80134