

How to replace a WOCA Mop head



1. Hold the mop head side up. Unscrew white plastic piece (shown in photo) counterclockwise.
2. Replace with clean mop head and screw in white plastic piece clockwise until secure.