
Nero

Bianca Mid Tall Basin Mixer

SPECIFICATION



PACKING INCLUDES

- 1x basin mixer
- 2x flexible hose
- 1x threaded pipe kit
- 1x base ring



-179

Dimensions are nominal measurements only.

50

Versions: 2022.08

Nero

IMPORTANT: Please read all of the instruction before installation.

General:


Nero recommends this product is installed by a licensed plumber in compliance with all relevant regional regulations. Do not hydrostatic test the installation with this mixer installled.Damage to the ceramic cartridge may occur. All pipe work must be thoroughly flushed prior to the installation of the mixer. In-line filters must be fitted on both hot and cold supplies to prevent foreign particles damaging the ceramic cartridge.

Do not remove the ceramic cartidge from the mixer when installing. After installation all connections must be checked for leaks. All outlets used primarily for personal hygiene shall deliver water

at a safe temperature as per regional regulations.

This mixer is not recommended for use in uncontrolled heating systems such as wet-backs or solar heating units unless a suitable tempering valve is fitted.

If limited water flow is experienced,locate aerator and filter washers and clean away foreign material as required. It is the responsibility of the installer to ensure a waterproof seal is achieved between the product and mounting surface. If in doubt about the rerquality of the seal, remove the product and reinstall.



1.Screw the flexible hoses into the mixer body, and fully hand tighten.

2.Pass the tail of flexible pipes through the hole on the bench top from above, and place the mixer in position on the bench top.Inspect to see if any alteration to the existing supply pipe work is required.Make any necessary alterations.

3. Tighten the fixing nut to treaded pipes compressing the galvanized washer and rubber washer from the under-side of the counter. Then tighten the 2 screws on the fixing nut.

4. Check that the mixer body is correctly positioned, fully tighten the fixing nut screw and fixing bolts firmly.

5.Connect the water supply pipes to the taile of flexible hoses with the hot water and cold water.Make sure the o-ring in the base ring seals completely around the hole in the mounting surface

6.Test for any leaks.