

Sony Alpha A DSRL Cameras									
	A100 A200 A230 A290 A300	A330 A350 A380 A390 A450	A500 A550 A560* A560L*	A580* A580L*	A700* A850 A900	A33* A37* A35* A55* A57*	A58* A65* A77* A77ii* A99* A99ii*	Dynax Series* Maxxum Series* xi Series* si Series* i Series*	RD-175
Lensbaby Lens									
Burnside 35	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Velvet 28	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Velvet 56 SE	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Velvet 56	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Velvet 85	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Circular Fisheye	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Trio 28	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Twist 60	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Composer Pro II with Sweet 35 Optic	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Composer Pro II with Sweet 50 Optic	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Composer Pro II with Sweet 80 Optic	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Composer Pro II with Edge 50 Optic	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Sol 45	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Sol 22	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Spark	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Discontinued									
Composer Pro II with Edge 80 Optic	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Composer Pro with Sweet 35 Optic	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Composer Pro with Sweet 50 Optic	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Composer Pro with Edge 80 Optic	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Composer Pro with Double Glass Optic	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Muse	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Scout	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Composer	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Control Freak	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Composer with Tilt Transformer	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Tilt Transformer	N/A		N/A		N/A	N/A	N/A	N/A	N/A

Sony Alpha E Mirrorless Cameras					
Lensbaby Lens	NEX-3* NEX-3N* NEX-C3* NEX-F3* NEX-5*	NEX-5N* NEX-5R* NEX-5T* NEX-6* NEX-7*	A3000* A3500* A5000*	A5100* A6000* A6300* A6500*	A7*/ A7 II*/ A7 III* A7R* / A7R II*/ A7R III* A7S* / A7S II* A9*
Burnside 35	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Velvet 28	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Velvet 56 SE	N/A		N/A		N/A
Velvet 56	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Velvet 85	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Circular Fisheye	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Trio 28	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Twist 60	Not Recommended		Not Recommended		Sony Alpha E - AP/ M
Composer Pro II with Sweet 35 Optic	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Composer Pro II with Sweet 50 Optic	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Composer Pro II with Sweet 80 Optic	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Composer Pro II with Edge 50 Optic	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Sol 45	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Sol 22	N/A		N/A		N/A
Spark	N/A		N/A		N/A
Discontinued					
Composer Pro II with Edge 80 Optic	N/A		N/A		N/A
Composer Pro with Sweet 35 Optic	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Composer Pro with Sweet 50 Optic	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Composer Pro with Edge 80 Optic	N/A		N/A		N/A
Composer Pro with Double Glass Optic	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Muse	N/A		N/A		N/A
Scout	N/A		N/A		N/A
Composer	N/A		N/A		N/A
Control Freak	N/A		N/A		N/A
Composer with Tilt Transformer	Sony NEX - AP/ M		Sony NEX - AP/ M		Sony NEX - AP/ M
Tilt Transformer	Sony NEX - AP/ M		Sony NEX - AP/ M		Sony NEX - AP/ M

Samsung NX Mirrorless Cameras						
Lensbaby Lens	Galaxy NX NX Mini	NX10 NX11 NX20 NX30	NX100 NX210 NX300	NX300m NX310 NX500	NX1000 NX1100 NX2000 NX3000 NX3300	NX1
Burnside 35	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Velvet 28	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Velvet 56 SE	N/A	N/A	N/A	N/A	N/A	N/A
Velvet 56	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Velvet 85	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Circular Fisheye	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Trio 28	N/A	N/A	N/A	N/A	N/A	N/A
Twist 60	N/A	N/A	N/A	N/A	N/A	N/A
Composer Pro II with Sweet 35 Optic	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Composer Pro II with Sweet 50 Optic	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Composer Pro II with Sweet 80 Optic	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Composer Pro II with Edge 50 Optic	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Sol 45	N/A	N/A	N/A	N/A	N/A	N/A
Sol 22	N/A	N/A	N/A	N/A	N/A	N/A
Spark	N/A	N/A	N/A	N/A	N/A	N/A
Discontinued						
Composer Pro II with Edge 80 Optic	N/A	N/A	N/A	N/A	N/A	N/A
Composer Pro with Sweet 35 Optic	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Composer Pro with Sweet 50 Optic	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Composer Pro with Edge 80 Optic	N/A	N/A	N/A	N/A	N/A	N/A
Composer Pro with Double Glass Optic	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Muse	N/A	N/A	N/A	N/A	N/A	N/A
Scout	N/A	N/A	N/A	N/A	N/A	N/A
Composer	N/A	N/A	N/A	N/A	N/A	N/A
Control Freak	N/A	N/A	N/A	N/A	N/A	N/A
Composer with Tilt Transformer	N/A	N/A	N/A	N/A	N/A	N/A
Tilt Transformer	N/A	N/A	N/A	N/A	N/A	N/A

Olympus 4/3 DSLR Cameras				
	E5 E3 E30	E420 E450	E500 E510 E520	E600 E620
Lensbaby Lens				
Burnside 35	N/A	N/A	N/A	N/A
Velvet 28	N/A	N/A	N/A	N/A
Velvet 56 SE	N/A	N/A	N/A	N/A
Velvet 56	N/A	N/A	N/A	N/A
Velvet 85	N/A	N/A	N/A	N/A
Circular Fisheye	N/A	N/A	N/A	N/A
Trio 28	N/A	N/A	N/A	N/A
Twist 60	N/A	N/A	N/A	N/A
Composer Pro II with Sweet 35 Optic	N/A	N/A	N/A	N/A
Composer Pro II with Sweet 50 Optic	N/A	N/A	N/A	N/A
Composer Pro II with Sweet 80 Optic	N/A	N/A	N/A	N/A
Composer Pro II with Edge 50 Optic	N/A	N/A	N/A	N/A
Sol 45	N/A	N/A	N/A	N/A
Sol 22	N/A	N/A	N/A	N/A
Spark	N/A	N/A	N/A	N/A
Discontinued				
Composer Pro II with Edge 80 Optic	N/A	N/A	N/A	N/A
Composer Pro with Sweet 35 Optic	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M
Composer Pro with Sweet 50 Optic	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M
Composer Pro with Edge 80 Optic	N/A	N/A	N/A	N/A
Composer Pro with Double Glass Optic	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M
Muse	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M
Scout	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M
Composer	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M
Control Freak	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M
Composer with Tilt Transformer	N/A	N/A	N/A	N/A
Tilt Transformer	N/A	N/A	N/A	N/A

Fuji X Mirrorless Cameras				
Lensbaby Lens	X-T1* X-T2* X-T3* X-H1* X-T10* X-T20* X-T100* X-Pro1* X-Pro2*	X-E1* X-E2* X-E2S* X-E3*	X-M1*	X-A1* X-A2* X-A3* X-A5* X-A10*
Burnside 35	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Velvet 28	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Velvet 56 SE	N/A	N/A	N/A	N/A
Velvet 56	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Velvet 85	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Circular Fisheye	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Trio 28	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Twist 60	N/A	N/A	N/A	N/A
Composer Pro II with Sweet 35 Optic	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Composer Pro II with Sweet 50 Optic	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Composer Pro II with Sweet 80 Optic	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Composer Pro II with Edge 50 Optic	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Sol 45	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Sol 22	N/A	N/A	N/A	N/A
Spark	N/A	N/A	N/A	N/A
Discontinued				
Composer Pro II with Edge 80 Optic	N/A	N/A	N/A	N/A
Composer Pro with Sweet 35 Optic	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Composer Pro with Sweet 50 Optic	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Composer Pro with Edge 80 Optic	N/A	N/A	N/A	N/A
Composer Pro with Double Glass Optic	N/A	N/A	N/A	N/A
Muse	N/A	N/A	N/A	N/A
Scout	N/A	N/A	N/A	N/A
Composer	N/A	N/A	N/A	N/A
Control Freak	N/A	N/A	N/A	N/A
Composer with Tilt Transformer	N/A	N/A	N/A	N/A
Tilt Transformer	N/A	N/A	N/A	N/A