

Canon Cameras

Lensbaby Lens	Rebel Series KISS Series	1D/ 1DMKiiN/ 1Dx/ 1DxMKii 5D/ 5DMKii/ 5DMKiii/ 5D MKiv / 5DS/ 5DSr 6D/ 6DMKii	7D/ 7DMKii	10D	50D	100D	500D	Canon RF
				20D	60D	300D	550D	
				20Da	60Da	350D	700D	
				30D	77D	400D	1000D	
				40D	80D	450D		
Burnside 35	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M		N/A
Velvet 28	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M		Canon RF - AP/ M
Velvet 56 SE	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M		Canon RF - AP/ M
Velvet 56	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M		Canon RF - AP/ M
Velvet 85	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M		Canon RF - AP/ M
Circular Fisheye	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M		N/A
Trio 28	N/A	N/A	N/A	N/A	N/A	N/A		Canon RF - AP/ M
Twist 60	Not Recommended	Canon EF - AP/ M	Not Recommended	Not Recommended	Not Recommended	Not Recommended		N/A
Composer Pro II with Sweet 35 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M		Canon RF - AP/ M
Composer Pro II with Sweet 50 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M		Canon RF - AP/ M
Composer Pro II with Sweet 80 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M		Canon RF - AP/ M
Composer Pro II with Edge 50 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M		Canon RF - AP/ M
Sol 45	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M		Canon RF - AP/ M
Sol 22	N/A	N/A	N/A	N/A	N/A	N/A		N/A
Spark	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M		N/A
Spark 2.0	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M		Canon RF - AP/ M
Obscura 50	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M		N/A
Obscura 16	N/A	N/A	N/A	N/A	N/A	N/A		Canon RF - AP/ M
Discontinued								
Composer Pro II with Edge 80 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M			Canon EF - AP/ M
Composer Pro with Sweet 35 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M			Canon EF - AP/ M
Composer Pro with Sweet 50 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M			Canon EF - AP/ M
Composer Pro with Edge 80 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M			Canon EF - AP/ M
Composer Pro with Double Glass Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M			Canon EF - AP/ M
Muse	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M			Canon EF - AP/ M
Scout	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M			Canon EF - AP/ M
Composer	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M			Canon EF - AP/ M
Control Freak	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M			Canon EF - AP/ M
Composer with Tilt Transformer	N/A	N/A	N/A	N/A	N/A			N/A
Tilt Transformer	N/A	N/A	N/A	N/A	N/A			N/A

Nikon DSLR Cameras												
Lensbaby Lens	D40 D40x D50 D60 D70	D70s D80 D90 D100	D3000 D3100 D3200 D3300 D3400 D3500	D5000 D5100 D5200 D5300 D5500 D5600	D7500	D7000 D7100 D7200	D200 D300 D300s D500	D3/ D3x/ D3s D4/ D4s D5	D600 D610 D700 D750	D800 D800e D810 D810a D850	Df	Z50, Z6, Z7
Burnside 35	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Velvet 28	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Velvet 56 SE	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Velvet 56	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Velvet 85	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Circular Fisheye	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Trio 28	N/A		N/A	N/A		N/A	N/A	N/A	N/A	N/A	N/A	N/A
Twist 60	Not Recommended		Not Recommended	Not Recommended		Not Recommended	Not Recommended	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Composer Pro II with Sweet 35 Optic	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Composer Pro II with Sweet 50 Optic	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Composer Pro II with Sweet 80 Optic	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Composer Pro II with Edge 50 Optic	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Sol 45	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Sol 22	N/A		N/A	N/A		N/A	N/A	N/A	N/A	N/A	N/A	N/A
Spark	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Spark 2.0	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Obscura 50	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Obscura 16	N/A		N/A	N/A		N/A	N/A	N/A	N/A	N/A	N/A	Nikon F - AP/ M
Discontinued												
Composer Pro II with Edge 80 Optic	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Composer Pro with Sweet 35 Optic	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Composer Pro with Sweet 50 Optic	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Composer Pro with Edge 80 Optic	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Composer Pro with Double Glass Optic	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Muse	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Scout	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Composer	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Control Freak	Nikon F - M		Nikon F - M	Nikon F - M		Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M	Nikon F - AP/ M
Composer with Tilt Transformer	N/A		N/A	N/A		N/A	N/A	N/A	N/A	N/A	N/A	N/A
Tilt Transformer	N/A		N/A	N/A		N/A	N/A	N/A	N/A	N/A	N/A	N/A

Sony Alpha A DSRL Cameras									
Lensbaby Lens	A100 A200 A230 A290 A300	A330 A350 A380 A390 A450	A500 A550 A560* A560L*	A580* A580L*	A700* A850 A900	A33* A37* A35* A55* A57*	A58* A65* A77* A77ii* A99* A99ii*	Dynax Series* Maxxum Series* xi Series* si Series* i Series*	RD-175
Burnside 35	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Velvet 28	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Velvet 56 SE	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Velvet 56	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Velvet 85	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Circular Fisheye	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Trio 28	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Twist 60	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Composer Pro II with Sweet 35 Optic	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Composer Pro II with Sweet 50 Optic	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Composer Pro II with Sweet 80 Optic	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Composer Pro II with Edge 50 Optic	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Sol 45	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Sol 22	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Spark	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Spark 2.0	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Obscura 50	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Obscura 16	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Discontinued									
Composer Pro II with Edge 80 Optic	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Composer Pro with Sweet 35 Optic	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Composer Pro with Sweet 50 Optic	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Composer Pro with Edge 80 Optic	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Composer Pro with Double Glass Optic	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Muse	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Scout	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Composer	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Control Freak	Sony Alpha A - AP/ M		Sony Alpha A - AP/ M		Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M	Sony Alpha A - AP/ M
Composer with Tilt Transformer	N/A		N/A		N/A	N/A	N/A	N/A	N/A
Tilt Transformer	N/A		N/A		N/A	N/A	N/A	N/A	N/A

Sony Alpha E Mirrorless Cameras

Lensbaby Lens	NEX-3* NEX-3N* NEX-C3* NEX-F3* NEX-5*	NEX-5N* NEX-5R* NEX-5T* NEX-6* NEX-7*	A3000* A3500* A5000*	A5100* A6000* A6300* A6500*	A7*/ A7 II*/ A7 III* A7R* / A7R II*/ A7R III* A7S* / A7S II* A9* A9II* A1*
Burnside 35	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Velvet 28	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Velvet 56 SE	N/A		N/A		N/A
Velvet 56	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Velvet 85	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Circular Fisheye	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Trio 28	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Twist 60	Not Recommended		Not Recommended		Sony Alpha E - AP/ M
Composer Pro II with Sweet 35 Optic	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Composer Pro II with Sweet 50 Optic	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Composer Pro II with Sweet 80 Optic	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Composer Pro II with Edge 50 Optic	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Sol 45	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Sol 22	N/A		N/A		N/A
Spark	N/A		N/A		N/A
Spark 2.0	N/A		N/A		N/A
Obscura 50	N/A		N/A		N/A
Obscura 16	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Discontinued					
Composer Pro II with Edge 80 Optic	N/A		N/A		N/A
Composer Pro with Sweet 35 Optic	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Composer Pro with Sweet 50 Optic	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Composer Pro with Edge 80 Optic	N/A		N/A		N/A
Composer Pro with Double Glass Optic	Sony Alpha E - AP/ M		Sony Alpha E - AP/ M		Sony Alpha E - AP/ M
Muse	N/A		N/A		N/A
Scout	N/A		N/A		N/A
Composer	N/A		N/A		N/A
Control Freak	N/A		N/A		N/A
Composer with Tilt Transformer	Sony NEX - AP/ M		Sony NEX - AP/ M		Sony NEX - AP/ M
Tilt Transformer	Sony NEX - AP/ M		Sony NEX - AP/ M		Sony NEX - AP/ M

Samsung NX Mirrorless Cameras

	Galaxy NX NX Mini	NX10 NX11 NX20 NX30	NX100 NX210 NX300	NX300m NX310 NX500	NX1000 NX1100 NX2000 NX3000 NX3300	NX1
Lensbaby Lens						
Burnside 35	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Velvet 28	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Velvet 56 SE	N/A	N/A	N/A	N/A	N/A	N/A
Velvet 56	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Velvet 85	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Circular Fisheye	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Trio 28	N/A	N/A	N/A	N/A	N/A	N/A
Twist 60	N/A	N/A	N/A	N/A	N/A	N/A
Composer Pro II with Sweet 35 Optic	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Composer Pro II with Sweet 50 Optic	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Composer Pro II with Sweet 80 Optic	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Composer Pro II with Edge 50 Optic	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Sol 45	N/A	N/A	N/A	N/A	N/A	N/A
Sol 22	N/A	N/A	N/A	N/A	N/A	N/A
Spark	N/A	N/A	N/A	N/A	N/A	N/A
Spark 2.0	N/A	N/A	N/A	N/A	N/A	N/A
Obscura 50	N/A	N/A	N/A	N/A	N/A	N/A
Obscura 16	N/A	N/A	N/A	N/A	N/A	N/A
Discontinued						
Composer Pro II with Edge 80 Optic	N/A	N/A	N/A	N/A	N/A	N/A
Composer Pro with Sweet 35 Optic	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Composer Pro with Sweet 50 Optic	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Composer Pro with Edge 80 Optic	N/A	N/A	N/A	N/A	N/A	N/A
Composer Pro with Double Glass Optic	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M	Samsung NX - AP/ M
Muse	N/A	N/A	N/A	N/A	N/A	N/A
Scout	N/A	N/A	N/A	N/A	N/A	N/A
Composer	N/A	N/A	N/A	N/A	N/A	N/A
Control Freak	N/A	N/A	N/A	N/A	N/A	N/A
Composer with Tilt Transformer	N/A	N/A	N/A	N/A	N/A	N/A
Tilt Transformer	N/A	N/A	N/A	N/A	N/A	N/A

Olympus 4/3 DSLR Cameras

	E5 E3 E30	E420 E450	E500 E510 E520	E600 E620
Lensbaby Lens				
Burnside 35	N/A	N/A	N/A	N/A
Velvet 28	N/A	N/A	N/A	N/A
Velvet 56 SE	N/A	N/A	N/A	N/A
Velvet 56	N/A	N/A	N/A	N/A
Velvet 85	N/A	N/A	N/A	N/A
Circular Fisheye	N/A	N/A	N/A	N/A
Trio 28	N/A	N/A	N/A	N/A
Twist 60	N/A	N/A	N/A	N/A
Composer Pro II with Sweet 35 Optic	N/A	N/A	N/A	N/A
Composer Pro II with Sweet 50 Optic	N/A	N/A	N/A	N/A
Composer Pro II with Sweet 80 Optic	N/A	N/A	N/A	N/A
Composer Pro II with Edge 50 Optic	N/A	N/A	N/A	N/A
Sol 45	N/A	N/A	N/A	N/A
Sol 22	N/A	N/A	N/A	N/A
Spark	N/A	N/A	N/A	N/A
Spark 2.0	N/A	N/A	N/A	N/A
Obscura 50	N/A	N/A	N/A	N/A
Obscura 16	N/A	N/A	N/A	N/A
Discontinued				
Composer Pro II with Edge 80 Optic	N/A	N/A	N/A	N/A
Composer Pro with Sweet 35 Optic	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M
Composer Pro with Sweet 50 Optic	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M
Composer Pro with Edge 80 Optic	N/A	N/A	N/A	N/A
Composer Pro with Double Glass Optic	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M
Muse	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M
Scout	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M
Composer	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M
Control Freak	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M	Olympus 4/3 - AP/ M
Composer with Tilt Transformer	N/A	N/A	N/A	N/A
Tilt Transformer	N/A	N/A	N/A	N/A

Fuji X Mirrorless Cameras				
Lensbaby Lens	X-T1* X-T2* X-T3* X-H1* X-T10* X-T20* X-T100* X-Pro1* X-Pro2*	X-E1* X-E2* X-E2S* X-E3*	X-M1*	X-A1* X-A2* X-A3* X-A5* X-A10*
Burnside 35	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Velvet 28	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Velvet 56 SE	N/A	N/A	N/A	N/A
Velvet 56	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Velvet 85	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Circular Fisheye	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Trio 28	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Twist 60	N/A	N/A	N/A	N/A
Composer Pro II with Sweet 35 Optic	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Composer Pro II with Sweet 50 Optic	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Composer Pro II with Sweet 80 Optic	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Composer Pro II with Edge 50 Optic	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Sol 45	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Sol 22	N/A	N/A	N/A	N/A
Spark	N/A	N/A	N/A	N/A
Spark 2.0	N/A	N/A	N/A	N/A
Obscura 50	N/A	N/A	N/A	N/A
Obscura 16	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Discontinued				
Composer Pro II with Edge 80 Optic	N/A	N/A	N/A	N/A
Composer Pro with Sweet 35 Optic	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Composer Pro with Sweet 50 Optic	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M	Fuji X - AP/ M
Composer Pro with Edge 80 Optic	N/A	N/A	N/A	N/A
Composer Pro with Double Glass Optic	N/A	N/A	N/A	N/A
Muse	N/A	N/A	N/A	N/A
Scout	N/A	N/A	N/A	N/A
Composer	N/A	N/A	N/A	N/A
Control Freak	N/A	N/A	N/A	N/A
Composer with Tilt Transformer	N/A	N/A	N/A	N/A
Tilt Transformer	N/A	N/A	N/A	N/A