

SOFT FOCUS II

See how creative you can get with the all new Soft Focus II

With an aperture range from f/2.5 to f/22, the Soft Focus II optic from Lensbaby is a new-and-improved version of one of the earliest and, recently, most sought-after optics in Lensbaby's Optic Swap System, the original Soft Focus optic. Compatible with all of Lensbaby's current and legacy Optic Swap lens bodies, the Soft Focus II improves on its predecessor by adding a 12-blade manually adjustable internal aperture to its unique and versatile drop-in magnetic aperture system.

When shot at its brightest aperture settings, the Soft Focus II creates an impressionistic image with subtle sharp detail beneath. Rendering a color palette tending toward soft pastels at brighter apertures and producing a remarkably flat field of focus, this optic makes possible images that are impossible to achieve with any other lens. Stopped down to f/8 or darker, the Soft Focus II produces beautifully detailed, traditionally sharp images with a large central area of focus and out of focus edges on full frame sensors and 35mm film. Quick variability of the optical effect from impressionistic and full of glow to contrasty and sharp is made possible by the internal 12-blade aperture that is adjusted by turning the front of the optic.



Aperture Comparison:

f/2.8



f/8



**Need a little more info?
Find answers to all of your
SOFT FOCUS II questions here:**

[View FAQs](#)

Check out our [Blog](#) and [YouTube channel](#) for more Soft Focus II tips and tricks!

Detailed instructions on back

USER GUIDE

SOFT FOCUS II

50mm | f/2.5

1



- Lensbaby's Soft Focus II lens is a manual focus lens. Adjust your camera's diopter for your eyesight to ensure that what looks sharp through the lens is sharp in your photo. For instructions, consult your camera's manual or visit lensbaby.com/diopter
- Lensbaby의 전周 Soft Focus II가 수동 초점 렌즈입니다. 렌즈를 통해 선명하게 보이는 모습 그대로 사진에서도 선명하게 보이도록 사용자의 시력에 맞춰 Diopter를 조절하십시오. 자세한 내용은 카메라 사용 설명서를 참조하거나 lensbaby.com/diopter 를 방문하십시오.
- Lensbaby Soft Focus IIはマニュアルフォーカスレンズです。あらかじめカメラの視度調整をご自身の視力に合わせてセットし、ピントを確認できるようにしてからお使いください。詳細については、お使いのカメラの使用説明書をご覧ください。

2



- Set camera mode. Adjust camera menu settings to shoot or release without lens.
- 設定相機模式。调节相机选项单设定值为无镜头拍摄或无镜头快门释放。
- 카메라 모드를 설정합니다. 촬영または 렌즈なし 취외 시에는, 카메라 메뉴의 설정을 조정합니다.
- 카메라 모드를 z 설정하십시오. 촬영하거나 '렌즈 없이 릴리스' 하려면, 카메라 메뉴 설정을 조정하십시오.

3



- Adjust aperture
- 調整光圈
- 絞りを調節します。
- 조리개를 조절하십시오.

4

- Aperture determines the size of your area of focus and the amount of swirl in the blur. For the most dramatic effect, start at aperture setting f/2.5.
- 光圈可決定焦距區域的大小和模糊中的螺旋效果。若要獲得最強烈的效果，請從光圈設定 f/2.5 開始
- 開口部は、焦点の範囲の大きさと同鮮明のスワールの量を決定します。最も劇的な効果のためには、開口部設定を少なくとも f/2.5 にしてください。
- 조리개의 수치는 초점 범위와 초점 밖의 흐릿한 배경 효과를 결정합니다. 드라마틱한 효과를 극대화하려면 조리개 수치를 f/2.5 이상으로 설정하십시오.

LENSBABY®

www.lensbaby.com | [@lensbabyusa](https://twitter.com/lensbabyusa)

Contact us at:
customerhappiness@lensbaby.com
facebook.com/lensbaby

U.S.A & Canada Returns:
lensbaby.com/returns

- Please refer to the web link below for your country's warranty:
- 請參考以下為您所在國家的保修的網頁鏈接
- 日本國內での保証は付属の保証書をご確認ください。
- 국가별 보증은 아래 웹 링크를 참조해 주십시오.

lensbaby.com/warranty



© Shelly Corbett



© Melissa Bissell



© Elizabeth Wilson



© Kate Kanters

© Regina Boston



© Melissa Tokariwski