


# **F77**

**AUTOMATIC**

INSTRUCTION MANUAL

# F77 AUTOMATIC Watch parts



# F77 AUTOMATIC Crown Position



**1** Manual winding

**2** Setting the date

**3** Setting the time

# F77 AUTOMATIC Manual winding




## 1 Manual winding

To manually wind the movement twist the crown clockwise approximately 8-9 times and keep wearing .

★ *This an automatic winding movement. with daily wear the movement will wind itself and will not require manual winding. but it is not worn for a certain amount of time, its power reserve (in this model, 38 hours) is exhausted, and the watch stops.*

# F77 AUTOMATIC Setting the date



1. **1** Crown out to the **2** position

2. Turn the crown counterclockwise for date setting.

★ Do not set the date between 9 PM and 3 AM, otherwise the day may not change properly.

3. Push back to **1** position

## F77 AUTOMATIC Setting the time



1. **1** Crown out to the **3** position

2. Turn the crown to set minute and hour hands

3. Push back to **1** position

*Nivada  
Grenchen*