


# DEPTHMASTER

AUTOMATIC

INSTRUCTION MANUAL

# DEPTHMASTER Watch parts



# DEPTHMASTER Crown Position




1 Position normal

2 Manual winding

3 Setting the date

4 Setting the time

# DEPTHMASTER Manual winding



1. **1** Position turn the crown unclockwise , unscrew crown  
To **2** position

2. **2** Manual winding

To manually wind the movement twist the crown clockwise  
approximately 8-9 times and keep wearing .

★ *This an automatic winding movement. with daily wear the  
movement will wind itself and will not require manual winding.  
but it is not worn for a certain amount of time, its power reserve  
(in this model, 38 hours) is exhausted, and the watch stops.*

3. Screw in crown back to normal position **1**

# DEPTHMASTER Setting the date




1. **2** Crown out to the **3** position

2. Turn the crown counterclockwise for date setting.

★ Do not set the date between 9 PM and 3 AM, otherwise the day may not change properly.

3. Screw in crown back to normal position **1**

# DEPTHMASTER Setting the time



1. **2** Crown out to the **4** position

2. Turn the crown counterclockwise for date setting.

★ Do not set the date between 9 PM and 3 AM, otherwise the day may not change properly.

3. Screw in crown back to normal position **1**

*Nivada  
Grenchen*