


NO.

Installation Instructions


1



01	Z01		M12x125L	2PCS
	Z02		Φ13xΦ24x2.5t	4PCS
	Z03		M12	2PCS
	Z04		8 mm	1PCS
	Z05		19 mm	1PCS

	AB1		AC1
1PCS		1PCS	


2



01	Z06		M12x130L	5PCS
	Z02		Φ13xΦ24x2.5t	10PCS
	Z03		M12	5PCS
	Z04		8 mm	1PCS
	Z05		19 mm	1PCS

	C07		C08		C09
1PCS		1PCS		1PCS	
	AC2				
1PCS					


3



01	Z07		M12x135L	2PCS
	Z02		Φ13xΦ24x2.5t	4PCS
	Z03		M12	2PCS
	Z04		8 mm	1PCS
	Z05		19 mm	1PCS

	AD1		AD2
1PCS		1PCS	


4



01	Z08		M12x165L	2PCS
	Z02		Φ13xΦ24x2.5t	4PCS
	Z03		M12	2PCS
	Z04		8 mm	1PCS
	Z05		19 mm	1PCS

	AE1		AE2
1PCS		1PCS	

5



01	Z09		M10x60L	2PCS
	Z10		M10x35L	4PCS
	Z11		Φ10.5xΦ20x2.0t	6PCS
	Z12		6 mm	1PCS

	J01		J02
1PCS		1PCS	