



SPECIFICATION

Chroma Gel 30W LED FREEZE LAMP

Output power	30W
Number of bulbs	12 LED bulbs
Size	175 x 155 x 75 mm
Weight	459 g
Accessory: Universal AC adapter	
Input Power	100V - 240V 50/60Hz
Output power	12V  2.5A



USAGE



Due to the design of this device, please enter your hand & make sure it is placed inside the lamp right in the middle and adjust the fingers to a suitable position while curing.

One Year Limited Warranty

What your warranty covers.

* Any defects in material or workmanship. However Beauty Hair's liability will not exceed the purchase price of the product.

For how long?

* One year from the date of original purchase.

To get your product serviced call: 0208 365 1300

What your warranty does not cover.

* Damage from commercial use.

* Damage from misuse, abuse or neglect.

* Products that have been modified.

* General wear and tear.


* Products used outside the country of purchase. * Shipping and handling costs associated with replacement of the unit.

* Consequential or incidental damages.

Please contact the manufacturer to dispose of this item correctly.

CHROMA[®]
30 Watt LED GEL
FREEZE LAMP

TERMS OF EACH COMPONENT IN NAIL LAMP



USER GUIDELINE

1. Select the desired time to start the lamp.
2. When the button on the lamp is illuminated place the hand in the tray.
3. The lamp will turn off automatically once the time is up.
4. For toenails, please remove the bottom tray from the lamp, and place the toenails under the lamp.

SAFETY

1. Unplug the lamp when not in use.
2. DO NOT use the lamp in or around water.
3. Do NOT look directly into the lamp.
4. Certain cosmetics can cause sensitivity to the light. Discontinue immediately.
5. DO NOT overexpose the nails or the skin to the light.
6. DO NOT use gels that are not formulated to be cured under the lamp, as this may result in severe chemical burns.
7. Do not leave hands or feet longer than 5 minutes in the LED Lamp.



WARNING!



CHROMA®

30 Watt LED GEL

FREEZE LAMP

IMPORTANT SAFETY INSTRUCTIONS & USER

GUIDE PLEASE RETAIN FOR FUTURE REFERENCE

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

This item is not to be used for hospital or medical use.

Read all instructions before use.

KEEP AWAY FROM WATER.

DANGER- As with most electrical appliances, electrical parts are electrically live when the switch is off.

To reduce the risk of death by electrical shock:

- Always unplug the appliance after use.
- Never use while bathing.
- Never place the appliance near water or other liquid.
- If the appliance falls into water unplug it immediately - never reach in the water to get it.
- Never use the appliance if the cord is damaged or twisted or bent.

CORD SAFETY

- Never pull or yank the cord.
- Always inspect the cord before each use.
- Never wrap the cord around the appliance.

DO NOT OPERATE THE APPLIANCE IF THE CORD SHOWS ANY SIGN OF DAMAGE OR IF THE APPLIANCE WORKS INTERMITTENTLY OR STOPS WORKING COMPLETELY.

WARNING - To reduce the risk of burns, electrocution, fire or injury to persons:

- This appliance should never be left unattended when plugged in. Turn it off by the switch and unplug the electrical cord from the mains.
- This appliance should only be used for its intended use as described in the manual.
- Never operate this appliance if it is damaged or has a damaged cord or plug. If it is not working properly or if it is dropped in water or damaged in any way then do not use.
- Do not leave hands or feet longer than 5 minutes in the LED Lamp.

Return this item to a service centre for examination or repair

NOTE: Beauty Hair does not have any authorised service centres.

If this appliance is still under warranty please call: 0208 365 1300.

- Keep the cord away from hot surfaces. Never twist or wrap the cord around the appliance.
- Never use while sleeping.
- Do not use outdoors.
- Do not use an extension cord with this appliance.
- Do not use a voltage converter with this appliance.



**BEAUTY HAIR PRODUCTS LTD,
UNIT 8, TRIUMPH TRADING ESTATE, TARIFF ROAD, LONDON,
N17 0EB**

TEL: 0208 365 1300

MADE IN TAIWAN

Product Code:CG-LED-F30W

www.beautyhair.co.uk

info@beautyhair.co.uk

WEE number: WEE/AD2158ZV



This symbol means that this product must be disposed of correctly as it can impact the environment if disposed of incorrectly.



This symbol means do not use this appliance while in the bath or in the shower or near any water.