

Bulldog GR250 High Security Door Lock Fitting Instruction



Note. When fitting the lock to hinged doors, the cover plate with the integral bracket should be fitted to whichever door opens first.

1. Position the template provided in the position where the lock is to be fitted. Mark the position of the holes.
2. Prior to drilling the holes, ensure that there is clear access to the rear of the door and that no internal braces or cables etc are going to inhibit fitting the lock or the door operation.
3. Drill the holes using a 8.5mm diameter drill.
4. Pass the head of the coach bolt through the large hole of the bracket and slide it to the end of the slot (2 bolts/bracket).

Note. On the bracket where the loose cover is fitted, ensure the head of the bolt is also engaged in the loose cover.

5. With the bolts in place within the bracket, pass the bolts through the drilled holes.
6. Attach the brackets using the nuts and washers provided.
7. Check that the lock bolt aligns with both brackets by inserting it and locking it in position.
8. Reduce the length of the fixing bolt if necessary.

To Operate the Lock

Unlocking. Fully insert the key, then rotate ½ turn clockwise and withdraw the lock bolt.

Locking. With the lock bolt in the unlocked position, insert it through both brackets and turn the key ½ turn anti-clockwise. Remove the key.

We have taken every care in the design and manufacture of this security device and we believe that it is an effective deterrent. However, we cannot guarantee that it will resist the efforts of the most determined thief, and as such we do not accept any liability for loss or damage caused by theft, vandalism or other illegal activity against property to which this device is fitted.

Lock Lubrication.

IMPORTANT - To ensure free movement of the lock, spray lock mechanism & ball bearings with WD40 (or equivalent) minimum every four months.

Key Security. Enter your key number here:

IMPORTANT - Your Bulldog product is supplied with two keys. Make a note of your personal key number in the space provided above and **keep it in a safe place.** Should you lose your keys, replacements can only be obtained from Bulldog.