




SHOT CLOCK

Quick Start Guide

V 1.0





GAMING
SUPPORT

Introduction

Gaming Supports Shot Clock is a physical clock on the poker table that counts down the time players have left to act on their hand.


Once the clock reaches zero without the player having decided to call, fold, bet, or raise, a player's hand is either dead, or a player is forced to buy more time from the bank.



Getting ready



1. Before using the Shot Clock, ensure that the battery is charged.
2. Slide the switch on the bottom from "off" to "standby".
3. Press and hold the blue button for 2 seconds.
4. A beep will sound and the numbers on the displays will light up.
5. The Shot Clock is now ready for use.

Operation




1. Hold blue button for 2 seconds to wake clock from standby mode.

2. Press green button once to start countdown.




3. Press green button again to reset to start value.


4. Press blue button after start to add time to countdown.



Hold green button for 6 seconds to switch clock to standby mode. If the Shot Clock is not used for 10 minutes it will automatically switch to standby mode.



Settings




Default time

- Hold green button for 3 seconds to set default time.
- Press green to increase (+).
- Press blue to decrease (-).
- Hold green button for 3 seconds to save settings.


Display intensity

- Hold blue button for 3 seconds to set display intensity.
- Press green to increase (+).
- Press blue to decrease (-).
- Hold blue button for 3 seconds to save settings.




Charging the battery

If the decimal dots in the display are visible or the unit will not start, the battery is running low.



Charge the clock before continuing.

Plug the charger into the micro-USB port on the bottom side of the Shot Clock



The yellow LED will show charging is in progress.



When fully charged the green led on the top will illuminate.



- Only use the battery charger as supplied



Gaming Support BV
Industrieweg 29
3044 AS Rotterdam
The Netherlands
+31 10 524 11 50

Gaming Support Inc
289 Pilot Road
NV 89119 Las Vegas
United States of America
+1 702 944 9224

gamingsupport.com