



R7 classic down-stream piston 1st stage (yoke)

No.	Part No.	Description
1	YK-01	Yoke knob
2	MR7-02	Yoke
3	MR7-03	
4	MR7-04	Dust cap
5	MR7-05	Gas inlet / Yoke retaining nut
6	MR7-06	Cone mesh filter
7	MR7-07	NBR O-ring (AS568-011 N90)
8	MR7-08	Main housing
9	MR7-09	High-pressure seat
10	MR7-10	NBR O-ring (AS568-008 N70)
11	MR7-11	Pressure adjustment shim - Thin
12	MR7-12	Main spring
13	MR7-13	Pressure adjustment shim - thick
14	MR7-14	Piston
15	MR7-15	NBR O-ring (AS568-023 N70)
16	MR7-16	Ambient pressure chamber
17	MR7-17	LP port plug
18	MR7-18	LP port plug O-ring (AS568-011 N70)
19	MR7-19	HP port plug
20	MR7-20	HP port plug O-ring (AS568-012 N90)

R7 1st STAGE (DIN) - less yoke parts (MR7-01 ~ 07) + the following

No.	Part No.	Description
D1	MR7-D1	NBR O-ring (AS568-112 N90)
D2	MR7-D2	DIN gas inlet
D3	MR7-D3	NBR O-ring (AS568-012 N90)
D4	MR7-D4	DIN hand wheel
D5	MR7-D5	DIN inlet post
6	MR7-06	Mesh filter
7	MR7-07	NBR O-ring (AS568-011 N90)
D8	MR7-D8	Dust cap

R7 1st STAGE SERVICE KIT

Part No.	Description
MR7-100	Servicing kit for R7 with YOKE connector
MR7-101	Servicing kit for R7 with DIN connector