



*Island Hopper*®

## **OWNER'S MANUAL**

*FOR WATER TRAMPOLINE ATTACHMENTS:*

---

***Double Blaster  
Bounce n Slide  
Island Runner***

---

**READ OWNERS MANUAL BEFORE USE**

Neoprene Distributors: DBA Aqua Sports Technology  
11859 Lakeshore North | Auburn, California 95602  
Phone: (800) 893-9677 | Fax: (530) 268-7786

[www.watertrampolines.com](http://www.watertrampolines.com) | [www.banana-boats.com](http://www.banana-boats.com) | [www.islandhopperproducts.com](http://www.islandhopperproducts.com)

# **Contents**

- 3** Operator Warnings
- 4** Safety Warnings
- 5** Watersports Responsibility Code
- 6** Proper Inflation
- 7** Double Blaster
- 8** Island Runner
- 9** Bounce N Slide
- 10** Repairs
- 11** Care, Operations and Storage
- 12** Limited Warranty

**Water sports can be safe and fun. This operators manual is designed to increase your knowledge of the water trampoline attachment. It should also make you aware of the potentially dangerous conditions that can be found with any water sports.**



# WARNING

## USE OF THIS PRODUCT AND PARTICIPATION IN THIS SPORT INVOLVES INHERENT RISKS OF INJURY OR DEATH.

By opening and assembling this product, you are agreeing (1) to be bound to the terms set forth below and (2) to require anyone using this product to be bound by such terms. If you are unwilling to be bound by these terms, return this product (un-opened) for a full refund.

**ASSUMPTION OF RISK:** Use of this product and any of its components involves certain inherent risks, dangers, and hazards which can result in serious personal injury and death. In using the product, you freely agree to assume and accept any and all known and unknown risks of injury while using this equipment. The risks inherent in the sport can be greatly reduced by abiding by the Warning Guidelines listed in this Owner's Manual and by using common sense.

**RELEASE AND WAIVER OF CLAIMS AGREEMENT:** In consideration of the sale of the product to you, you hereby agree to the fullest extent permitted by law as follows:

**TO WAIVE ANY AND ALL CLAIMS** that you have or may in the future have against Neoprene Distributors International, DBA Aqua Sports Technology Inc., including its distributors and dealers, resulting from use of this product and any of its components.

**TO RELEASE** Neoprene Distributors International, DBA Aqua Sports Technology, Inc. from any and all liability for any loss, damage, injury, or expense that you or any users of this product may suffer, or that your next of kin may suffer, as a result of the use of this product, due to any cause whatsoever, including negligence or breach of contract on the part of Neoprene Distributors International, DBA Aqua Sports Technology, Inc. in the design or manufacture of this product and any of its components.

**ARBITRATION:** In further consideration of the sale to you of this product and any of its components, you hereby agree to submit to binding arbitration any and all claims which you believe you may have against Neoprene Distributors International, DBA Aqua Sports Technology arising from the use of any Neoprene Distributors International, DBA Aqua Sports Technology equipment or products. The arbitration shall be pursuant to the rules of the American Arbitration Association. Arbitration shall be commenced within (1) year from the date on which any alleged claim first arose. Further, the arbitration shall be held in White Salmon, Washington unless otherwise mutually agreed to by all parties. The submission to the American Arbitration Association shall be unlimited and the arbitration award may be enforced by any Court of competent jurisdiction.

**BINDING EFFECT OF AGREEMENT:** In the event of your death or incapacity this Agreement shall be effective and binding upon your heirs, next of kin, executors, administrators, assigns, and representatives.

**ENTIRE AGREEMENT:** In entering into this Agreement, you are not relying upon any oral or written representations other than what is set forth in this agreement and the Neoprene Distributors International, DBA Aqua Sports Technology Owner's Manual.

Neoprene Distributors International *DBA Aqua Sports Technology*  
Auburn, CA 95602 | (800) 893-9677

# Safety Warnings

THESE WARNINGS ARE POSTED ON YOUR *ISLAND HOPPER* WATER TRAMPOLINE ATTACHMENT. READ BEFORE PROCEEDING WITH SET UP.



## WARNINGS

**Use of this product and participation in water sports involves inherent risks of injury or death.**

1. Children should be under the supervision of an adult at all times. This product is not intended for use by children under the age of 5 years.
2. Always maintain a safe distance of 15ft (4.57m) between the product and any dock, hard object, platform, boat or pier.
3. This water trampoline attachment is designed for use in water only. **DO NOT USE ON LAND, ON OR AROUND HARD SURFACES, OR SWIMMING POOLS.**
4. Be sure to securely anchor the water trampoline attachment before each use. Check your jump surface connections regularly.
5. All users should wear a US Coast Guard approved personal flotation device (PFD) when using this water trampoline attachment.
6. The water trampoline attachment is designed to be used in a large body of water with a **MINIMUM DEPTH OF 8 FEET**. Always check that the swimming area around the water trampoline attachment is free of obstructions including submerged logs, sandbars and rocks. Ask about local conditions before use.
7. Never use your water trampoline attachment after sunset, or in poor lighting.
8. Avoid use around swimmers and areas that are subject to boat traffic.
9. Do not swim or play under your water trampoline attachment.
10. Do not dive off the water trampoline attachment, always enter the water feet first.
11. Never use in stormy weather, or in rough water conditions or high winds. Seek shelter when lightning is present or expected, **DO NOT** stay on product.
12. **NEVER USE YOUR WATER TRAMPOLINE ATTACHMENT WHILE UNDER THE INFLUENCE OF ALCOHOL OR DRUGS.**
13. Be in control while using your water trampoline attachment. Do not attempt acrobatic maneuvers while using your water trampoline attachment. Avoid bouncing too high.
14. Do not tow your water trampoline attachment with riders aboard.
15. Always secure from unauthorized or unsupervised use while not using your product. It is best to remove the water trampoline attachment from the water and deflate or remove the jump surface and ladder to avoid unsupervised use.
16. Inspect your water trampoline attachment and replace any worn, defective or missing parts before each use.
17. **DO NOT EXCEED THE RECOMMENDED NUMBER OF USERS FOR THIS PRODUCT.**
18. **MAXIMUM JUMPING LOAD IS 200 POUNDS. CHECK AND SECURE YOUR HARDWARE TIES WHEN JUMPING WITH MAXIMUM LOADS.**
19. This water trampoline attachment should not be used as a personal flotation device.

*If you have any questions regarding the Island Hopper watersports products, please contact Aqua Sports Technology at 1 (800) 893-9677.*

# ***Watersports Responsibility Code***

**ANYONE PLANNING TO USE ANY WATER TRAMPOLINE  
ATTACHMENT MUST REVIEW OWNER'S MANUAL BEFORE USE**

## **WATERSPORTS RESPONSIBILITY CODE**

**Be aware that there are risks in watersports activities that good judgment and personal awareness can help reduce. To increase your enjoyment of watersports activities, follow the ten elements of the Code.**


IN WATERSPORTS IT IS YOUR RESPONSIBILITY TO:

- ALWAYS familiarize yourself with applicable laws, waterways, and inherent risks
- ALWAYS have a capable observer in addition to driver, and agreed on hand signals
- ALWAYS wear a properly fitted life jacket approved by your country's agency
- ALWAYS read user's manual and inspect equipment before use
- ALWAYS ride under control, at proper speeds, and within your limits
- ALWAYS turn ignition off when anyone is near watercraft power drive unit
- ALWAYS stay clear of engine exhaust to avoid Carbon Monoxide poisoning
- NEVER "Platform Drag" or touch swim platform while the engine is running
- NEVER ride near swimmers, shallow water, other boats, or obstacles
- NEVER operate watercraft or ride under the influence of alcohol or drugs

# Proper Inflation

1. **Lay out the water trampoline attachment on a flat surface.** Make sure there are no sharp objects that could damage or cause a puncture to the water trampoline attachment.

3. **Locate the Valve.** To open the valve, push the spring stem down and turn counter clockwise and the spring will stay down and the valve will remain open. Inflate using any type of air blowing device such as a shop vac, leaf blower, or foot pump. Blowers can be found on our website. Take a picture of this QR with your smart phone to find that web page quickly.



- **Fill the tube with air until firmly inflated.** It should be hard to the touch. **This will be about 2 PSI.**
- When inflation is complete, quickly remove the inflator, **close the valve by pushing the valve stem down and turning clockwise so it pops out.** Then put on the valve cap.
- If you don't have a valve adapter you can still inflate your water trampoline attachment, simply put the nozzle of your shop vacuum or any power inflator to the open valve and blow the air in. Once the tube is firmly inflated, pull the nozzle away and quickly close the valve, needle spring popped up. **To top off and make your product firm, take inflator nozzle and butt it back up to the closed valve and force air in. This will allow a little air to get in and top off product without letting the air escape.**

*Air fluctuations are normal depending on outside air and water temperatures. In the cool morning, your tube may look like it is going flat due to a leak when it actually is soft due to the air temperature. **TOP OFF WITH AIR WHEN NEEDED AND KEEP TUBE FIRM WHEN IN USE.***

Visit our website for helpful videos on inflation:  
[watertrampolines.com/valveuse/](http://watertrampolines.com/valveuse/)  
[watertrampolines.com/product-informational-videos/](http://watertrampolines.com/product-informational-videos/)

# Double Blaster

## Double Blaster assembly instructions

*No special tools are required, everything fits together.*

**When attaching to water bouncer, only use two outside straps.**

*The following items will be in one box:*

1. Take three straps and tie over trampoline tube.
2. Wrap the straps under the trampoline frame.
3. Take straps and wrap under and around the trampoline tube.
4. Thread the three straps through the three D-rings on the Double Blaster.
5. Tighten the three straps so the double blaster attachment snugs up to the water trampoline tube. Tie off excess straps.
6. Double Blaster only needs to be inflated about 60% to work correctly.






# Island Runner

## Island Runner instructions

1. See proper inflation instructions on page 6.
2. The Island Runner attaches to your water trampoline via the nylon straps and D-rings.
3. Take strap and wrap around trampoline tube over frame.
4. Pull strap through D-rings and make sure it is tight to tube. Tie off remaining strap.
5. Anchor your runner using any of the D-rings.






# Bounce N Slide

## Bounce N Slide assembly instructions

1. Find slide attachment area on water trampoline/bouncer.
2. Place Bounce N Slide on area and attach front water trampoline D-rings to lower front Bounce N Slide D-rings using bungee cords.
3. Do the same for the 2 D-rings inside the water trampoline's tube that will attach to the 2 top D-rings on the Bounce N Slide.
4. Make sure Bounce N Slide is tight and secure to water trampoline/bouncer and you are ready to use.



# Repairs and Patching

A repair kit is included. See our step by step repair guide below.

**CALL TO ORDER - (800) 893-9677**

- 1. FIND THE HOLE —** Inflate the tube until firm and clean with damp towel. While the tube is DRY, go over it with your hands and feel for the puncture. Often the small holes look like a scratch so check these areas first. If you find an area that you suspect is a hole, wet the area and feel for the air. Sometime you will HEAR the whistle of a small hole before you feel it. BE PATIENT. START ON THE OUTSIDE TOP AND WORK DOWN ON EACH PANEL.
- 1A. Find Quick-Fix-Patches** that were included with the product. Once you find the hole, deflate, and use these patches to repair small holes. For larger holes and more permanent repairs see below.
- 2. CIRCLE THE HOLE WITH A PEN AND THEN DEFLATE —** This will help you locate the area to patch once the tube is deflated.
- 3. CLEAN THE AREA —** Make sure the area around the hole is cleaned and dry. Then cut a patch that will fit over the hole allowing a few inches larger for gluing surface.
- 4. APPLY PVC GLUE AND PATCH —** You can find this adhesive at any West Marine or Hardware store under “inflatable PVC adhesive.” Place patch over hole and allow to dry for 15 minutes.
- 5. OUTLINE THE PATCH WITH AQUA SEAL** (sold separately) let stand for 24 hours. Aqua Seal dries very slowly, but the repair will be PERMANENT once it is sealed. Patches without Aqua Seal will work, but will not be permanent and eventually can come off.



Using your smart phone's camera, TAP open the browser link that appears. This will take you to the Island Hopper inflation and repairs webpage.

# Care, Operations and Storage

## Follow these guidelines for safe use and years of enjoyment

Protect from the sun whenever possible. We strongly suggest you apply 303 Protectant for UV protection and weathering. (DO NOT USE ARMORAL OR PRODUCTS THAT CONTAIN SILICONE OR PETROLEUM DISTILLATES). Apply the 303 to the runner to the water line. Spray on and let set for 5 minutes then wipe and buff with clean cloth. APPLY 303 WHEN YOU FIRST SET UP YOUR "ISLAND RUNNER" AND EVERY 45 DAYS FOR BEST RESULTS. It usually takes about 30 minutes to make the float tube shine and look great. Standard application is about 16 ounces. 303 Protectant is available at your local boating retailer or can be purchased by calling the Island Hopper service representative at (530) 268-7310.

When you know that your water trampoline attachment will not be used for extended periods of time, it is best to move it to a shady area or deflate the tube and store it in the shade. DO NOT LEAVE UP YEAR AROUND. REMOVE FROM THE WATER AND STORE DURING WINTER. To clean, use a mild soap and water and then wipe dry. Avoid the use of cleaners unless they state that they are ok to use on rubber products and do not contain petroleum distillates. Reapply 303 after cleaning.

Inspect the water trampoline attachment for proper inflation before each use. Proper inflation will extend the life of your water trampoline attachment and ensure that it bounces at its maximum potential. Also, your tube will appear to have lost air (get softer) in the cool of the morning and immediately after it comes in contact with the cold water. DO NOT MISTAKE THIS FOR A PUNCTURE OR DEFECT. Add air to your tube after one or two days of use. Maximum expansion will occur in the heat of the day. On very hot days (over 100°) you may need to adjust the air pressure in each chamber throughout the day. WARNING: seam ruptures due to over inflation are not covered under warranty! Each flotation tube will have to be checked for the air pressure in each chamber. Check the air pressure by pressing your palm against the flotation tube. It will feel firm, and leave a slight depression (it should make a thump sound). Sand and dirt can tear the fine fibers of the jumping mat, which will shorten the life of the mat and cause holes and tears to appear. If your mat develops a hole, it will need to be replaced.

## Storing the water trampoline attachment after use:

1. Wipe down water trampoline attachment. If attachment is dirty, clean with mild soap and water first then dry completely. DO NOT USE ARMORAL OR PRODUCTS CONTAINING PETROLEUM DISTILLATES.
2. Be sure the water trampoline attachment is dry before storing.
3. Store in a dry covered cool area. Note - storing in damp or humid areas area can cause glued areas such as seams and nose cones to separate. Avoid areas that have mice or rodents.

*Rodents, such as muskrats, are attracted to the PVC vinyl and rubber materials and have been known to chew holes and cause damage. Maintaining proper air pressure will discourage them from chewing on the water bouncer. However, the best thing to do to avoid this problem is to remove the water trampoline attachment from the water when not in use.*

# Workmanship Limited Warranty

The limited warranty set forth below is given by Neoprene Distributors International DBA: Neoprene Distributors International, DBA Aqua Sports Technology with respect to the *ISLAND HOPPER* brand water trampoline attachment product purchased and used in the United States. *ISLAND HOPPER* water trampoline attachment products are warrantied against defects in materials and workmanship for a period of one year from the date of original purchase for recreational (family) use and 60 days for commercial users. (Examples of commercial users: Camps, beach ride business operations or any commercial business that uses the product to earn profit)

If you feel the product is defective, **DO NOT RETURN IT TO RETAILER**. Call our *ISLAND HOPPER* service representative at (530) 268-7310 to discuss warranty options or for instructions on repairing your product. When returning a product under this limited warranty, a service representative must first issue a return authorization number. **Returned units not supported by a return authorization number will be refused.** If the product is proven to be defective upon inspection, the defective unit will be repaired or replaced and returned. The warranty period for any replacement part shall begin upon shipment, but shall in no event exceed the warranty period of the defective product. When returning any part under this limited warranty, you must pack the part in its original or similar carton with a copy of the bill of sale or purchase invoice.

Please include a complete explanation of the problem. Shipping charges, if any, must be prepaid. Products or parts covered by this limited warranty will be returned to you without charge. This limited warranty covers all defects encountered in normal use of the product and does not apply in the following cases:

1. Loss or damage due to abuse, mishandling, alteration, accident, failure to follow operation instructions, poor maintenance or storage, over inflation or environmental conditions.
2. Warranty applies to manufacturing related defects. This warranty does not include air loss due to punctures or seam blowouts from over inflation or from expansion caused by exposure to excessive heat.
3. Warranty applies only to new water trampoline attachment products shipped in original carton.
4. No warranty will be honored for damage from storm or animals.
5. Wear and tear from normal use and weathering.
6. No other warranty applies except the above mentioned, nor can any be given by any person, firm or corporation without the expressed written consent of Neoprene Distributors International DBA: Neoprene Distributors International, DBA Aqua Sports Technology.

**USER ASSUMES ALL RISKS AND LIABILITY FOR LOSS, DAMAGE, OR INJURY TO YOU OR YOUR PROPERTY, AND TO OTHERS AND THEIR PROPERTY, ARISING OUT OF USE, MISUSE, OR INABILITY TO USE THE *ISLAND HOPPER* WATER TRAMPOLINE ATTACHMENT.**



Neoprene Distributors: DBA Aqua Sports Technology  
11859 Lakeshore North | Auburn, California 95602  
Phone: (800) 893-9677 | Fax: (530) 268-7786

[www.watertrampolines.com](http://www.watertrampolines.com) | [www.banana-boats.com](http://www.banana-boats.com) | [www.islandhopperproducts.com](http://www.islandhopperproducts.com)

*Additional updates may be available at: [www.watertrampolines.com/safety\\_info.asp](http://www.watertrampolines.com/safety_info.asp)*