


Note: Do not allow children to play or use this electronically operated furniture unsupervised. Due to the risk of injury, make sure that there is nothing underneath the footrest when it is returned to the closed position. When not in use, leave the chair in an upright and closed position. Keep hands and feet clear of mechanism and only the occupant should operate the mechanism to avoid injury.

Questions? Give us a shout at info@nurtureand.com

Back

Nurture& The Swivel

INSTRUCTION MANUAL






Cover

Hi. Hello!

Congratulations on your Nurture& purchase - we are so excited for you to join the #madeforsharedmoments community, and enjoy THE SWIVEL with your growing family.



Parts List

Description	Sketch	Qty.
The Swivel		1 pc.
Power cord Part A		1 pc.
Power cord Part B		1 pc.

- To avoid injury, use care when assembling
- Adult supervision required when used by children - this piece of furniture should be treated as a piece of furniture and is NOT a toy
- Assemble and use on level surface
- Maximum load: 150 kg /330 lbs. Exceeding this weight may damage product and cause potential injury


Before you assemble: check for damaged or missing parts (email info@nurtureand.com for help), use the carton as a working surface to prevent product damage before assembly, and gather all parts prior to assembly.

Unpackage power cord part B from the box that is tied to the mechanism at the bottom of the chair.



Connect power cord part B with power cord part A.

Plug power cord part B into the wall!



Questions? Give us a shout at info@nurtureand.com

Inside