


AshChromics

Enjoy things in #ANewLight with FADES® Sunglasses featuring patented electrochromic technology. Our lenses respond to environmental lighting changes in under 2 seconds, without the need of UV light. Fully charge them in 45 minutes and enjoy up to 5 days of outdoor adventures with advanced eye protection to always see the world in the best light.



Diagram

- ① Power button
- ② Power indicator LED light on inner right side
- ③ Charge indicator LED light
- ④ Charging port on bottom right side
- ⑤ Inner Lens Surface
- ⑥ Light Sensor

Turning the glasses ON/OFF:

- To turn the sunglasses ON, press the power button ① once.
NOTE: Power indicator LED light ② will blink green every 5 seconds when on.
- To turn the sunglasses OFF, hold the power button ① down for two seconds.
NOTE: Power indicator LED light ② will blink rapidly three times before turning off.
- When the battery is low, the charge indicator LED light ③ will not blink green, but instead light up in orange. Refer to “charging” instructions.


Charging

If the charge indicator LED light ③ on your sunglasses is lit up in orange, they need to be charged.

1. To charge, insert Micro-USB side of cable into sunglasses ④, and plug USB-A side of cable into your power source.
2. While charging, the charge indicator LED light ③ will display one of three patterns:
 - a. Solid orange - the battery is low and will take 30 to 45 minutes to fully charge
 - b. Blinking green - the battery is charging and should take 30 minutes to reach a full charge
 - c. Solid green - the battery is fully charged
3. Once the charge indicator LED light ③ is a solid green, remove the Micro-USB cable from the sunglasses.

FADES®

Auto-Darkening Sunglasses



Maintenance

- Clean lenses with microfiber cloth, lightly moistened with water or glass cleaner.

NOTE: Inner surface of lens ⑤ is pressure sensitive and should be handled with care. Pressing too hard may damage the lens and its functionality. Damage of the inner lens due to maintenance cleaning is not covered by the warranty.

- Periodically check that the light sensor ⑥ is not blocked by dust or debris.
- Avoid tampering with screws that secure the side earpiece covers and front frame, which will void the warranty.

Questions?

For additional information check out the FAQ section of our website.

Or you can reach out to us at:
Support@AshChromics.com

Enjoy seeing things in #ANewLight with
FADES® Sunglasses!