
01

KEY MAP


- 01 Left Buttom
- 02 Right Buttom
- 3 Scroll Wheel
- 04 DPI Switch
- 05 USB Connector



02

KEY MAP

- 01 Left Side Buttom
- 02 Left Side Buttom
- Right Side Buttom
- **100** Right Side Buttom
- 05 RGB Backlight




03

KEY MAP



- Power Switch
- Backlight Mode Switch

LEFT HAND USING & RIGHT HAND USING



FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired


for compliance could void the user's authority to operate the equipment.

encouraged to try to correct the interference by one or more of the following

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which


The device has been evaluated to meet general RF exposure requirement. The

USING THE USB WIRELESS RECEIVER COMPARTMENT




06


CHARGING



07

CONNECTIONS





Wired Connection or Charging with a Type-C Cable



Wirless Connection with an USB Receiver

SUPPORT & SERVICES



money-back guarantee for any reason



12-MONTH warranty for quality-related issues

If you have any questions, please feel free to contact us via business@ltcofficial.com

We are looking forward to your feedback and hope you enjoy your LTC Product!

LTE **USER MANUAL**

Mosh Pit WHM-01