User Manual



Camera Power

- Ensure you have a constant 12v-24v source and sufficient ground.
- Once camera has sufficient power, the white LED lights will flash on front of camera.
- This will mean camera is in pairing/power mode.

1. Wifi Camera App/Connection Instructions for IOS/Android Devices

- A. Download and install app "Cam Hi" from the "APP" store on Apple Devices
- B. Download and install app "Cam Hi Pro" Preferred or "Cam Hi" from the "PLAY" store on Android Devices




CAM HI PRO


B. Go to your settings icon on your phone/tablet, select the WiFi option and select IPCAM-xxx the ending digits may vary. The password will be 01234567.




- C. Close the settings tab and open the "CamHi" app.
- D. Click "Add Camera" on the Top of the screen.




E. Click the "Search camera from LAN" button.




F. From there you can select your camera in the list.



G. After you select your camera it will bring you back to the previous page and you can now select "Done" in the upper right corner.



H. Now you will see your camera in the list and it will say "ONLINE". You can now click on it to view.




2. Changing from Standard Definition "SD" to High Definition "HD"

• While viewing live feed of camera, click on the "SD" button on bottom right of feed. You will then see it change to "HD". This will mean you are now in High Definition mode.



3. Enabling microphone on camera

 While viewing live feed of the camera, click on the "Sound" button on the botton left of the screen. This will enable the microphone located on the camera to be played through your IOS/Android device. To speak back, click and hold the microphone icon on the right side on the screen, release to listen.



4.Turning LED spot lights on

Press the "Light bulb" icon on the top of the screen and select "color" to turn on the LED spotlights and "auto" to use the infrared instead.



5. Resetting the camera

- On the rear of the camera, click and hold down the reset button for 10 seconds.
- Once camera resets, the LED light will flash once. The camera is ready to be reconnected.

*FOR ANY PROBLEMS CONTACT US AT **SALES@RBSCO.CA***