



Care and Storage Instructions

Garment Care

Please read entire instructions before starting laundry process.

DO NOT DRY CLEAN
HAND WASH ONLY

Prepare the garment for washing. Ideally, pick a warm dry day to assist with drying.

- Tuck plugs into its zipped pockets and close zips.
- Check pockets for any other items you may have left in them and remove.

Prepare wash basin or sink

- Use a clean sink or other large basin and fill with lukewarm or cold water.
- Put in a capful of mild detergent (like Woolite); for best results follow directions on detergent bottle.
- Gently swirl the clothing in the sink for a few minutes or just enough to aggrivate the dirt from the garment. A soft brush can be used around the heavily soiled areas, such as collars.
- Drain sink and use clean tap water to thoroughly rinse the clothing until no more soap suds are visible.
- Turn off water or drain sink then GENTLY squeeze out the water; do not wring or twist.
- Remove from sink and lay flat between towels to soak up as much water as you can; the more you soak up the quicker it will dry.
- After soaking up most of the water, you may want to hang up the garment so the air can circulate inside and out for faster drying; consider laying a towel down or hang over sink to catch any additional water that may be left.
- Allow garment to completely air dry before using or storing gear for the riding season.

Once the garment is completely dry

- Gently tap plugs to confirm they are dry.
- Enjoy your refreshed garment.

DO NOT IRON
DO NOT PUT IN DRYER
DO NOT USE HAIR DRYER OR HEAT GUN

Plug Care

Please read entire instructions before storing gear for the season.

- Check for cracked or exposed wire on cabling and plugs.
- DO NOT CUT OR SPLICE CABLE OR PLUGS, THAT WILL RESULT IN VOIDING THE WARRANTY.
- DO NOT USE PETROLEUM BASED PRODUCTS ON PLUGS.



- Check the health of the interior of the plugs, look for wear, corrosion and loose plugs.
- Check the battery harness; this is the single most important piece in your gear, it is important to maintain its health.
- If you need a new battery harness contact: www.gerbing.co.uk

Prepare the garment for storage

- **Once you have taken steps to clean the garments and confirmed they are dry inside and out.**
- Inspect cable and plugs then tuck the plugs into its zippered pockets and close zippers.
- Check pockets for any other items you may have left in them and remove.

Gear can be stored in a dry temperate closet, folded, laid flat or hung on a hanger.