

Connecting product

1 power off

1 open


2 connect wires base

3 fix to the wall (base)

4 assemble (base+cover)

5 twist clockwise to tighten wire

3



Due to constant development, our App design and functionality might be different after updates. Please adjust accordingly or visit robertsmart.com (v01)

4 Electrical

1 Socket (Wi-Fi)

2 Select 2.4GHz Wi-Fi Network and enter password.

3 confirm indicator rapidly blink

4 Next

5 hold 5sec to reset

6 Select 2.4GHz Wi-Fi Network and enter password.


7 if fast blinking 1x 0.5sec (next step 9)

8 230V max distance 25m

9 blinking 1x 0.5sec

10 Done

(1) ALL other cases, reset device, choosing no-flashing option (next step 7)



8 confirm indicator rapidly blink

9 Adding device...

10 Done

For Your convenience we strongly recommend to rename your product. Please choose intuitive description

