

PADHOLDR PRO SERIES AIR

APPLE IPAD AIR • APPLE IPAD AIR 2

STEP 3



- Slide your iPad in the holder and center it.
- Push the spacers in the slotted holes against the iPad and tighten down the bolts.
- Engage the lock by pressing it in, then move the lock so the pin is against the iPad.
- Tighten the 2 bolts for the lock to keep it in place.

STEP 4



Your iPad is now able to freely slide in and out of the holder while the lock is disengaged. To lock the iPad in the holder, press in on the face of the lock cylinder. To unlock, insert the key in to the lock and turn clockwise.

Unit and parts have a 1 year manufacturer warranty. For technical assistance, product support, comments, or concerns, please contact us.

Self-installation instructions and advice are provided for your convenience. It is your responsibility to determine if you have the knowledge, skills, and physical ability required to properly perform an installation. PadHoldr Products, LLC. shall have no liability for damage or injury resulting from the installation or use of any PadHoldr or third party products. It is your responsibility to ensure that all products are installed in adherence with local laws and regulations and in such a manner as to allow a vehicle to be operated safely and without distraction. PadHoldr Products, LLC. product warranties do not cover the installation, removal or re-installation of any product.