



PADHOLDER IFIT CLASSIC/AIR

HOLDER SETUP AND TABLET INSTALLATION GUIDE



SETUP

A. With the included allen-key tool, remove the four bolts from the holder face-plate (a), and set the face-plate aside.


B. Ensure tensioners are loose (b), then carefully attempt to fit your tablet on to the back-plate within the spacers and tensioners.

C. Place the face-plate over the installed tablet and determine if you'll need to change out the installed spacers to adjust the width of the holder to fit your tablet firmly.

D. Once the correct size spacers and tensioners are installed. Re-install the face-plate and four bolts (a).

E. Adjust the tensioners (b) so they're firmly pressed against the sides of your tablet, then tighten them in position.

Note: For quick removal of tablet, do not install one of the tensioners on either side of the holder to enable you to slide your tablet in and out easily.



There are several ways to attach your holder to its mounting device.

1. Use the 8-32 bolts included to attach the mounting device to the back of the holder.

2. Use the bolts, nuts, and washers to attach the holder to the mounting device.

0.75"