

Thank you for your purchase of the Artistic® LED Business Hours Sign which allows you to easily set your hours of operation for each day of the week.

Please follow the easy set-up instructions below:




Diagram 1




Diagram 2



Diagram 3

Hanging & Installation

- 1) Locate parts (hang chains and power cord) located within the packaging
- 2) Hook the chains through the hanger tabs (Diagram 1) on both sides of the sign. When ready to hang on your wall, make sure to use wall anchors (not supplied) before hanging the chain over a wall hanger hook or screws.
- 3) Insert barrel plug of AC adaptor into the input receptor on the right side of the sign and plug adaptor into your wall (Diagram 2)
- 4) Use only 100-240VAC input, 50 - 60Hz, 5 V - 4A output adaptor supplied
- 5) To turn on the sign, press the switch on the power cord to the "on" position (Diagram 3) and proceed below to program the Open and Closed settings.

Setting Hours of Operation

- 1) Locate the Control Panel on side of sign (Diagram 4)

"OPEN" Settings

- 1) Push K1 to select each day position, and push K2 to scroll to each time to set as desired (Diagram 5).
- 2) Push K3(+) to increase the time, and press K4(-) to decrease the time.
- 3) Hours will automatically save after 5 seconds of extended inactivity.

"CLOSED" Settings

- 1) Push K1 to select day positions and push K2 to scroll to each time setting.
- 2) Push K3 and K4 at the same time to alternate between "CLSD" and "Hours."




Diagram 4



Diagram 5

CAUTION: To Reduce The Risk Of Fire, Electric Shock Or Injury To Persons:

- This product is intended for indoor use only. Do not use in damp or wet locations
- Not for use with light dimmer circuits
- To reduce the likelihood of injury or damage mount only on a surface that is mechanically sound
- Do not use extension cords or outlets with inadequate current carrying capacity
- It is recommended to use a surge protector. Power surges ARE NOT covered under the warranty for this product
- Only use 100-240VAC input, 50 - 60Hz, 5 V - 4A output adaptor
- Do not handle adapter or sign with wet hands
- Disconnect power before handling or cleaning
- Do not spray liquid or aerosol cleaners directly onto sign. Use a dry or damp cloth for cleaning
- This product is fully assembled and ready to use. Do not attempt to disassemble or service as it will void the warranty
- Do not alter the plug or power supply cord in any way

LIMITED WARRANTY

Artistic Products LLC ("Artistic") warrants to the verified purchaser of the original product (hereinafter 'the Customer') that the Artistic product for which the Customer received this warranty was designed, developed and/or fabricated used all due reasonable commercial care and good manufacturing practices. Artistic's product shall be free from defects in material and workmanship for 1 Year from date of purchase as evidenced by a valid receipt. Artistic's sole obligation under this warranty is to repair or replace the product, at Artistic's option. Artistic must be notified in writing of any claim under this warranty within 30-days of any claimed lack of conformity of the product at the address hereinafter set forth.

WARRANTY LIMITATIONS: The duration of any implied warranty or condition, of merchantability, fitness for a particular purpose, or otherwise, on this product shall be limited to the duration of the express warranty set forth above. In no event, shall Artistic be liable for any loss, inconvenience or damage, whether direct, incidental, consequential or otherwise, resulting from breach of any express or implied warranty or condition, of merchantability, fitness for a particular purpose or otherwise with respect to this product, except as set forth herein. Some states or countries do not allow limitation on how long an implied warranty lasts and some do not allow exclusions or limitations of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which may vary, from location to location. This warranty shall be interpreted pursuant to the laws of the United States and the State of New York. The original English language version (meaning) of this warranty controls over all translations; Artistic is not responsible for any errors in translation of this warranty and/or any product instructions. This warranty is not intended to confer any additional legal, jurisdictional or warranty rights to you other than those set forth herein or required by law. If any portion of this warranty is held to be invalid or unenforceable for any reason, such finding will not invalidate any other provision. For products purchased in countries other than the United States, please contact the retailer from which the product was purchased.

WARRANTY EXCLUSIONS: This warranty does not cover products that have been modified, neglected, poorly maintained, misused or abused.

Return Authorization Requests: Requests for return authorization should be sent to Artistic Products LLC, 125 Commerce Drive, Hauppauge, NY 11788. 631- 435- 0200, attention: Customer Service.