



1850A (18GA. 50mm LONG. BRAD NAILER)

NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY
1	EXHAUST COVER	422-C-103	1	24	AIR PLUG	9032-B-005	1	48	GUIDE COVER B	1850A-G-003	1
2	BOLT (M5x25L)	Z-05-250	4	25	PLUG CAP	9032-B-006	1	49	BOLT (M4x16L)	ZN-04-160	2
3	CAP	1850A-C-001	1	26	GRIP	1850-B-004	1	50	DRIVER GUIDE	1850A-G-001	1
4	GASKET	1850A-C-002	1	27	VALVE SET	1850-V-P001	1	51	STEEL PLATE	F30-M-005	1
5	HEAD VALVE SEAL A	422-H-007	1	28	VALVE PLUNGER O-RING	CT64-V-004	1	52	PUSHER	1850A-M-103	1
6	CAP SPRING	422-H-006	1	29	VALVE PLUNGER	1850-V-007	1	53	PUSHER SPRING	1850-M-004	2
7	CAP O-RING	422-H-010	1	30	PLUNGER SPRING	1850-V-009	1	54	MAGAZINE A	1850A-M-001	1
8	HEAD VALVE O-RING	1850-H-004	1	31	PLUNGER O-RING	CT64-V-008	2	55	MAGAZINE B	1850A-M-002	1
9	HEAD VALVE	1850-H-201	1	32	PLUNGER	1850-V-010	1	56	BOLT (M4x8L)	Z-04-080	1
10	HEAD VALVE SEAL O-RING	1850-H-009	1	33	PLUNGER CAP O-RING	1013-V-011	1	57	SPRING WASHER (for M4)	W-04	1
11	HEAD VALVE SEAL B	422-H-008	1	34	PLUNGER CAP	1850-V-012	1	58	TWIN NUT	1850-M-012	2
12	COLLAR	1850-A-004	1	35	TRIGGER SPRING	1013-T-006	1	59	MAGAZINE END CAP	1850-L-101	1
13A	PISTON SET	1850-P-P101	1	36	PIN STOPPER O-RING	CT64-M-008	1	60	BUSHING	CT64-L-007	2
13	PISTON ASSEMBLY	1850-P-P102	1	37	TRIGGER A(OUT)	1850-T-001	1	61	BOLT (M4x12L)	ZN-04-120	2
14	PISTON O-RING	1850-P-003	1	38	PIN GUIDE	1850-T-003	1	62	CLICK LEVER	CT64-L-002	1
15	CYLINDER	1850-A-001	1	39	TRIGGER PIN	422-T-008	1	63	CLICK LEVER SPRING	CT64-L-004	1
16	CYLINDER O-RING	1850-A-005	2	40	TRIGGER B (IN)	1850-T-002	1	64	ROLL PIN (Φ3x18L)	R-30-180	1
17	CYLINDER GUIDE	1850A-A-002	1	41	ROLL PIN (Φ3x14L)	R-30-140	1	65	BRACKET	1850-M-106	1
18	CYLINDER GUIDE O-RING	1665-A-005	1	42	BOLT (M5x22L)	Z-05-220	2	66	BOLT (M5x12L)	Z-05-120	1
19	BUMPER	1850-A-003	1	43	GUIDE COVER A	1850A-G-102	1	68	BOLT (M4x6L)	ZN-04-060	2
20	NOZZLE	F30-B-007	1	44	CONTACT ARM	1850A-S-002	1	69	LOCK NUT (for M5)	NN-05	1
21	BODY	1850A-B-001	1	45	SAFETY LEVER	1850-S-111	1	70	PUSHER HOLDER	F30-M-013	2
22	END CAP O-RING	422-B-003	1	46	BOLT (M4x10L)	Z-04-100	2				
23	END CAP	422-B-002	1	47	SAFETY GUIDE COVER	1850A-S-010	1				

** All the parts of nailer can be changed for improvement and re-design without announcement.

(REV. : 2015/01/23)