



**FN34/90 (2" TO 3-1/2", CLIP HEAD, PAPER STRIP COLLATION)**

NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY
1	BOLT (M6x30L)	Z-06-300	4	33	AIR PLUG	JN2190-B-005	1	65	LOCK NUT (for M6)	NN-06	7
2	SPRING WASHER	W-06	4	34	VALVE SET	CS26/38-V-P001	1	66	DEPTH DIAL SET	JN2190-S-P001	1
3	BOLT (M6x20L)	ZN-06-200	1	35	VALVE O-RING	NV-V-001	1	67	SET SCREW (M4x4L)	ZS-04-040	1
4	EXHAUST COVER	JN2190-C-003	1	36	PLUNGER CAP O-RING	CT64-V-011	1	68	BALL SPRING	JN45R-S-012	1
5	EXHAUST COVER BUSHING	JN2190-C-007	1	37	VALVE	NV-V-003	1	69	BALL (Φ3.2)	B-032	1
6	EXHAUST COVER PLATE	JN2190-C-004	1	38	VALVE PIN (Φ3x14.2L)	NV-V-013	2	70	DEPTH DIAL	JN2190-S-011	1
7	CAP	FN2190-C-001	1	39	VALVE PLUNGER O-RING (UP)	NV-V-004	1	71	CONTACT TEETH	FN84/90-S-010	1
8	GASKET	FN34/90-C-002	1	40	VALVE PLUNGER	NV-V-007	1	72	RING PLATE	JN2190-S-014	1
9	PISTON STOPPER	JN2190-H-005	1	41	VALVE PLUNGER O-RING (MID)	CT64-V-005	1	73	MAGAZINE	FN84/90-M-001	1
10	HEAD VALVE SPRING	JN2190-H-006	1	42	VALVE PLUNGER O-RING (LOW)	NV-V-006	1	74	NAIL GUIDE	FN84/90-M-005	1
11	HEAD VALVE O-RING (IN)	JN2190-H-003	1	43	PLUNGER O-RING	CT64-V-008	2	75	ROLL PIN (Φ3x9L)	R-30-090	1
12	HEAD VALVE	FN2190-H-001	1	44	PLUNGER SPRING	CT64-V-009	1	76	PUSHER LEVER	FN84/90-M-007	1
13	HEAD VALVE O-RING (OUT)	JN2190-H-004	1	45	PLUNGER	CS26/38-V-010	1	77	PUSHER LEVER SPRING	JN2190-M-008	1
14	HEAD VALVE SEAL	JN2190-H-002	1	46	PLUNGER CAP	NV-V-012	1	78	PUSHER	FN84/90-M-003	1
15	COLLAR	JN2190-A-004	1	47	ROLL PIN (Φ3x28L)	R-30-280	1	79	ROLL PIN (Φ3x36L)	R-30-360	1
16	PISTON SET	FN34/90-P-P101	1	48	ROLL PIN (Φ3x22L)	R-30-220	1	80	CONSTANT FORCE SPRING SET	JN2190-M-P001	1
17	PISTON O-RING	JN2190-P-003	1	49	TRIGGER SPRING	1013-T-006	1	81	NEELDE ROLLER	JN2190-M-010	1
18	PISTON ASSEMBLY	FN34/90-P-P102	1	50	TRIGGER PIN	FN2190-T-008	1	82	BOLT (ROUND HEAD M6x12L)	ZR-06-120	3
19	CYLINDER	FN34/90-A-001	1	51	TRIGGER A (OUT)	FN2190-T-001	1	83	NAIL STOPPER	FN34/90-L-006	1
20	CYLINDER O-RING	1665-A-006	1	52	PIN STOPPER O-RING	CT64-M-008	1	84	MAGAZINE END CAP	FN34/90-L-001	1
21	CYLINDER GUIDE	FN34/90-A-002	1	53	TRIGGER B (IN)	FN34/90-T-002	1	85	BUSHING	JN2190-L-007	1
22	CYLINDER GUIDE O-RING	FN34/90-A-006	1	54	ROLL PIN (Φ2.5x16L)	R-25-160	1	86	BRACKET	FN34/90-M-006	1
23	SUPPLY HOLE SEAL	JN2190-A-007	1	55	SAFETY GUIDE	FN34/90-S-003	1	87	BOLT (M6x18L)	Z-06-180	1
24	BUMPER	JN2190-A-003	1	56	BOLT (M5x8L)	ZN-05-080	1	88	NO MAR PAD	FN34/90-S-013	1
25	BODY	FN34/90-B-001	1	57	RING PLATE	FN34/90-G-005	1	89	HOOK	FN34/90-M-013	1
26	SUB GRIP	FN34/90-B-011	1	58	PROTECTOR	FN34/90-G-003	1	90	MAGAZINE HOOK BUSHING	JN2190-M-016	1
27	GRIP	FN34/90-B-004	1	59	NOSE O-RING	JN2190-G-002	1	91	HOOK BRACKET	FN2190-M-014	1
28	END CAP GASKET	FN34/90-B-003	1	60	NOSE	FN34/90-G-001	1	92	NUT (for M6)	N-06	1
29	END CAP	FN34/90-B-002	1	61	BOLT (M6x30L)	ZN-08-300	4	93	MAGAZINE HOOK SPACER	JN2190-M-015	2
30	SPRING WASHER	W-05	4	62	CONNECTOR SPRING	FN34/90-S-004	1	94	ROLL PIN (Φ3x30L)	R-30-300	1
31	BOLT (M5x20L)	Z-05-200	4	63	BOLT (M6x22L)	Z-06-220	1				
32	PLUG CAP	JN2190-B-006	1	64	CONTACT ARM	FN34/90-S-001	1				

\*\* All the parts of nailer can be changed for improvement and re-design without announcement.

(REV. : 2014/11/13)